

Stefan Tube

Introduction

This example illustrates the use of the Maxwell-Stefan diffusion model available with the Transport of Concentrated Species interface. It models multicomponent gas-phase diffusion in a Stefan tube in 1D. In this case, it is a liquid mixture of acetone and methanol that evaporates into air.

The concentration profiles are modeled at steady-state and validated against experimental data by Taylor and Krishna (Ref. 6).

Model Definition

The Stefan tube, shown in Figure 1, is a simple device used for measuring diffusion coefficients in binary vapors.




Figure 1: Schematic diagram of a Stefan tube.

At the bottom of the tube is a pool of mixture. The vapor that evaporates from this pool diffuses to the top of the tube, where a stream of air, flowing across the top of the tube, keeps the mole fraction of diffusing vapor there to be zero. The mole fraction of vapor above the liquid interface is at equilibrium. Because there is no horizontal flux inside the tube, you can analyze the problem using a 1D model geometry representing the distance between the liquid mixture surface and the top of the tube. The system composition of acetone, methanol, and air has been extensively investigated; both diffusion coefficients and composition have been measured at various positions within Stefan tubes. This makes it an ideal system for this model.

As a comparison, one experiment measured the mole fraction at the liquid interface to be $x_{\text{Ac}} = 0.319$ and $x_{\text{Me}} = 0.528$ where the pressure, p , was 99.4 kPa and the temperature, T , was 328.5 K. The length of the diffusion path was 0.238 m. The respective Maxwell-Stefan diffusion coefficients, D_{ij} , of the three binary pairs were calculated and are used in the model according to [Table 1](#).

TABLE 1: LABELS AND MAXWELL-STEFAN DIFFUSION COEFFICIENTS

COMPONENT	LABEL	D_{ij}	VALUE
Acetone	1	D_{12}	$8.48 \cdot 10^{-6} \text{ m}^2/\text{s}$
Methanol	2	D_{13}	$13.72 \cdot 10^{-6} \text{ m}^2/\text{s}$
Air	3	D_{23}	$19.91 \cdot 10^{-6} \text{ m}^2/\text{s}$

To model this problem, use the Transport of Concentrated Species interface with the Maxwell-Stefan diffusion model. It solves for the fluxes in terms of mass fractions for two of the three components. The mass fraction, ω , of the third is given by the two other ones. The three equations are:

$$\nabla \cdot \left[-\rho \omega_1 \sum_k [D_{1k} (\nabla x_k + (x_k - \omega_k) ((\nabla p)/p))] + D^T((\nabla T)/T) \right] = R - (\rho \mathbf{u} \cdot \nabla \omega_1)$$

$$\nabla \cdot \left[-\rho \omega_{2(1)} \sum_k [D_{2k} (\nabla x_k + (x_k - \omega_k) ((\nabla p)/p))] + D^T((\nabla T)/T) \right] = R - (\rho \mathbf{u} \cdot \nabla \omega_2)$$

$$\omega_3 = 1 - \omega_1 - \omega_2$$

where D is the diffusion coefficient (SI unit: m^2/s), p is the pressure (SI unit: Pa), T is the temperature (SI unit: K), \mathbf{u} is the velocity (SI unit: m/s), x and ω are mole and mass fractions, respectively, and the mixture density, ρ_{mix} (SI unit: kg/m^3), is a function of the average mixture mole fraction, M_{mix} (SI unit: kg/mol), according to [Equation 2](#):

$$M_{\text{mix}} = \sum_i x_i M_i \quad (1)$$

$$\rho_{\text{mix}} = \frac{p}{RT} M_{\text{mix}} \quad (2)$$

In this case, there is no imposed fluid velocity. However, there will appear a fluid velocity due to the diffusive fluxes. At the top of the tube the mass fractions are fixed, with the fraction of air being unity. At the bottom (at the liquid interface), the fractions are also fixed according to the previously mentioned experimental conditions. The fact that there is no air flux at the interface results in the following relation for the convective velocity, at steady state:

$$u = \frac{n_{\text{diff},3}}{\omega_3 \rho}$$

where $n_{\text{diff},3}$ is the diffusive mass flux of air (SI unit: $\text{kg}/(\text{m}^2 \cdot \text{s})$).

Results

Both the modeled and experimental steady-state mole fractions as a function of position are shown in [Figure 2](#).




Figure 2: Modeled and experimental (Ref. 6) steady-state mole fractions of: acetone, methanol, and air, in the Stefan tube.

We can see that the model reproduces the results from [Ref. 6](#) well, which means the Maxwell-Stefan equations can describe the mass transport process in the system accurately.

The Maxwell-Stefan diffusion formulation includes the conservation of mass. In the absence of chemical reactions (source terms) and convective contributions, the Maxwell-Stefan formulation results in zero net mass flux. In this example, the convective term is included, which you can see in the velocity profile in [Figure 3](#).




Figure 3: Velocity of the gas mixture in the Stefan tube.

References

1. C.F. Curtiss and R.B. Bird, "Multicomponent diffusion," *Ind. Eng. Chem. Res.*, vol. 38, p. 2515, 1999.
2. R.B. Bird, W. Stewart, and E. Lightfoot, *Transport Phenomena*, John Wiley & Sons, New York, 1960.
3. G.A.J. Jaumann, *Wien. Akad. Sitzungsberichte (Math.-Naturw. Klasse)*, vol. 120, p. 385, 1911.
4. J.O. Hirschfelder, C.F. Curtiss, and R.B. Bird, *Molecular Theory of Gases and Liquids*, Wiley, USA, 1954.
5. E.N. Fuller, P.D. Schettler, and J.C. Giddings, *Ind. Eng. Chem.*, vol. 58, p. 19, 1966.

6. R. Taylor and R. Krishna, *Multicomponent Mass Transfer*, John Wiley & Sons, NY, p. 21, 1993.

Application Library path: Chemical_Reaction_Engineering_Module/
Mixing_and_Separation/stefan_tube

Modeling Instructions

From the **File** menu, choose **New**.

NEW

In the **New** window, click **Model Wizard**.

MODEL WIZARD

- 1 In the **Model Wizard** window, click **ID**.
- 2 In the **Select Physics** tree, select **Chemical Species Transport>Transport of Concentrated Species (tcs)**.
- 3 Click **Add**.
- 4 Click **Add Mass Fraction**.
- 5 In the **Mass fractions** table, enter the following settings:

<u> </u>
w1
<u> </u>
w2
<u> </u>
w3
<u> </u>
- 6 Click **Study**.
- 7 In the **Select Study** tree, select **Preset Studies>Stationary**.
- 8 Click **Done**.

GEOMETRY I

Interval I (i1)

- 1 On the **Geometry** toolbar, click **Interval**.
- 2 In the **Settings** window for **Interval**, locate the **Interval** section.
- 3 In the **Right endpoint** text field, type 0.238.
- 4 Click **Build All Objects**.

GLOBAL DEFINITIONS

Next, add a set of model parameters by importing their definitions from a data text file provided with the **Application Library**.

Parameters

- 1 On the **Home** toolbar, click **Parameters**.
- 2 In the **Settings** window for **Parameters**, locate the **Parameters** section.
- 3 Click **Load from File**.
- 4 Browse to the model's Application Libraries folder and double-click the file `stefan_tube_parameters.txt`.

TRANSPORT OF CONCENTRATED SPECIES (TCS)

- 1 In the **Model Builder** window, under **Component 1 (comp1)** click **Transport of Concentrated Species (tcs)**.
- 2 In the **Settings** window for **Transport of Concentrated Species**, locate the **Transport Mechanisms** section.
- 3 From the **Diffusion model** list, choose **Maxwell-Stefan**.
- 4 Locate the **Species** section. From the **From mass constraint** list, choose **w3**.
- 5 In the **Model Builder** window's toolbar, click the **Show** button and select **Discretization** in the menu.
- 6 Click to expand the **Discretization** section. From the **Mass fraction** list, choose **Quadratic**.

Transport Properties 1

- 1 In the **Model Builder** window, expand the **Transport of Concentrated Species (tcs)** node, then click **Transport Properties 1**.
- 2 In the **Settings** window for **Transport Properties**, locate the **Model Input** section.
- 3 In the T text field, type `T0`.
- 4 In the p_A text field, type `p0`.
- 5 Locate the **Convection** section. Specify the \mathbf{u} vector as

$$\frac{-tcs.df1ux_w3x}{(w3*tcs.rho)} \quad \mathbf{x}$$

- 6 Locate the **Density** section. In the M_{w1} text field, type `M_ace`.
- 7 In the M_{w2} text field, type `M_met`.
- 8 In the M_{w3} text field, type `M_air`.

9 Locate the **Diffusion** section. In the D_{ik} table, enter the following settings:

I	D12	D13
D12	I	D23
D13	D23	I

Initial Values 1

- 1 In the **Model Builder** window, under **Component 1 (comp1)** > **Transport of Concentrated Species (tcs)** click **Initial Values 1**.
- 2 In the **Settings** window for **Initial Values**, locate the **Initial Values** section.
- 3 In the $\omega_{0,w1}$ text field, type w_{ace0} .
- 4 In the $\omega_{0,w2}$ text field, type w_{met0} .

Mass Fraction 1

- 1 On the **Physics** toolbar, click **Boundaries** and choose **Mass Fraction**.
- 2 Select Boundary 1 only.
- 3 In the **Settings** window for **Mass Fraction**, locate the **Mass Fraction** section.
- 4 Select the **Species w1** check box.
- 5 In the $\omega_{0,w1}$ text field, type w_{ace0} .
- 6 Select the **Species w2** check box.
- 7 In the $\omega_{0,w2}$ text field, type w_{met0} .

Mass Fraction 2

- 1 On the **Physics** toolbar, click **Boundaries** and choose **Mass Fraction**.
- 2 Select Boundary 2 only.
- 3 In the **Settings** window for **Mass Fraction**, locate the **Mass Fraction** section.
- 4 Select the **Species w1** check box.
- 5 Select the **Species w2** check box.

MESH 1

- 1 In the **Model Builder** window, under **Component 1 (comp1)** click **Mesh 1**.
- 2 In the **Settings** window for **Mesh**, locate the **Mesh Settings** section.
- 3 From the **Element size** list, choose **Extra fine**.
- 4 Click **Build All**.

STUDY 1

On the **Home** toolbar, click **Compute**.

RESULTS

Table 1

1 On the **Results** toolbar, click **Table**.

Import the experimental data for comparison.

2 In the **Settings** window for **Table**, type Experimental Mole Fractions in the **Label** text field.

3 Locate the **Data** section. Click **Import**.

4 Browse to the model's Application Libraries folder and double-click the file stefan_tube_exp.csv.

In order to reproduce the plot in [Figure 2](#), do the following:

Mass Fraction (tcs)

1 In the **Model Builder** window, under **Results** click **Mass Fraction (tcs)**.

2 In the **Settings** window for **ID Plot Group**, type Mole Fraction in the **Label** text field.

Line Graph

1 In the **Model Builder** window, expand the **Results>Mole Fraction** node, then click **Line Graph**.

2 Click in the **Graphics** window and then press Ctrl+A to select all domains.

3 In the **Settings** window for **Line Graph**, click to expand the **Title** section.

4 Click **Replace Expression** in the upper-right corner of the **y-axis data** section. From the menu, choose **Model>Component 1>Transport of Concentrated Species>tcs.x_w1 - Mole fraction**.

5 Locate the **y-Axis Data** section. Clear the **Description** check box.

6 Locate the **Title** section. From the **Title type** list, choose **None**.

7 Locate the **x-Axis Data** section. From the **Parameter** list, choose **Expression**.

8 In the **Expression** text field, type x.

9 Click to expand the **Coloring and style** section. Locate the **Coloring and Style** section. In the **Width** text field, type 2.

10 Click to expand the **Legends** section. Select the **Show legends** check box.

11 From the **Legends** list, choose **Manual**.

12 In the table, enter the following settings:

Legends

Acetone

Line Graph 2

- 1 Right-click **Results>Mole Fraction>Line Graph** and choose **Duplicate**.
- 2 In the **Settings** window for **Line Graph**, click **Replace Expression** in the upper-right corner of the **y-axis data** section. From the menu, choose **Model>Component 1>Transport of Concentrated Species>tcs.x_w2 - Mole fraction**.
- 3 Locate the **Legends** section. In the table, enter the following settings:

Legends

Methanol

Line Graph 3

- 1 Right-click **Results>Mole Fraction>Line Graph 2** and choose **Duplicate**.
- 2 In the **Settings** window for **Line Graph**, click **Replace Expression** in the upper-right corner of the **y-axis data** section. From the menu, choose **Model>Component 1>Transport of Concentrated Species>tcs.x_w3 - Mole fraction**.
- 3 Locate the **Legends** section. In the table, enter the following settings:

Legends

Air

Table Graph 1

- 1 In the **Model Builder** window, under **Results** right-click **Mole Fraction** and choose **Table Graph**.
- 2 In the **Settings** window for **Table Graph**, locate the **Data** section.
- 3 From the **x-axis data** list, choose **Column 1**.
- 4 Locate the **Coloring and Style** section. Find the **Line markers** subsection. From the **Marker** list, choose **Cycle**.
- 5 Find the **Line style** subsection. From the **Line** list, choose **None**.
- 6 Click to expand the **Legends** section. Select the **Show legends** check box.
- 7 From the **Legends** list, choose **Manual**.

8 In the table, enter the following settings:

Legends
Acetone exp.
Methanol exp.
Air exp.

Mole Fraction

- 1 In the **Model Builder** window, under **Results** click **Mole Fraction**.
- 2 In the **Settings** window for **ID Plot Group**, locate the **Plot Settings** section.
- 3 Select the **x-axis label** check box.
- 4 In the associated text field, type **Position (m)**.
- 5 Click to expand the **Legend** section. From the **Position** list, choose **Upper left**.

To reproduce [Figure 3](#), proceed as follows:

ID Plot Group 2

- 1 On the **Results** toolbar, click **ID Plot Group**.
- 2 In the **Settings** window for **ID Plot Group**, type **Velocity Field** in the **Label** text field.
- 3 Locate the **Plot Settings** section. Select the **x-axis label** check box.
- 4 In the associated text field, type **Position (m)**.

Line Graph 1

- 1 Right-click **Velocity Field** and choose **Line Graph**.
- 2 Click in the **Graphics** window and then press **Ctrl+A** to select all domains.
- 3 In the **Settings** window for **Line Graph**, click **Replace Expression** in the upper-right corner of the **y-axis data** section. From the menu, choose **Model>Component 1>Transport of Concentrated Species>Velocity field>tcs.u - Velocity field, x component**.
- 4 Locate the **x-Axis Data** section. From the **Parameter** list, choose **Expression**.
- 5 In the **Expression** text field, type **x**.
- 6 Click to expand the **Coloring and style** section. Locate the **Coloring and Style** section. In the **Width** text field, type **2**.
- 7 On the **Velocity Field** toolbar, click **Plot**.

