



Linear Buckling Analysis of a Truss Tower

Introduction

Trusses are commonly used to create light structures that can support heavy loads. When designing such a structure, it is important to ensure its safety. For a tower made of bars, buckling can cause the structure to collapse. This example shows how to compute the critical buckling load using a linear buckling analysis. The solution is compared with an analytical expression for critical load estimation for Euler buckling.

Then a slight prescribed deformation is applied to the structure, and a stationary study with load increasing up to critical buckling load is performed. This study puts in evidence the singularity at critical buckling load.

Model Definition

The model geometry consists of a 19 m tall truss tower with a rectangular section. The critical buckling load is computed using the linear buckling analysis available in the Truss interface.

The geometry is the periodic structure represented in [Figure 1](#) below. It consists of 19 blocks of trusses. Each block has a width of 0.45 m, a depth of 0.40 m and a height of 1.0 m. The trusses that are perpendicular to the ground are thicker and have an outer radius of 15 mm and an inner radius of 10 mm. The remaining trusses have an outer radius

of 10 mm and an inner radius of 7 mm. The tower is made out of structural steel, which is one of the predefined materials in the material library.




Figure 1: Geometry of the truss tower.

The tower is fixed at the ground level and a vertical load is applied at the top.

One fourth of the unit load is applied at each point of the tower top so that the critical load factor returned by the linear buckling analysis corresponds to the load that would cause the collapse of the structure.

A second study is performed to put in evidence the singularity at critical buckling load. To do so, the geometry is slightly deformed according to the first mode shape to initiate the buckling deformation. The load is then increased above the calculated critical buckling load in a stationary study using an auxiliary sweep.

Results and Discussion

For a simple column the critical buckling load is given by the Euler buckling formula

$$F_c = \frac{\pi^2 EI}{(KL)^2}$$

where E is the Young's modulus, I is the area moment of inertia, L is the unsupported length of the column and K is the column effective length factor.

For a column with one end fixed and the other end free to move laterally, $K = 2$.

For a tower like the one in this example with 4 main bars in the axial direction, the area of moment of inertia of the section can be computed as:

$$I = 4S\left(\frac{h}{2}\right)^2$$

where h is the distance between the vertical bars, and S the cross section area of the bars.

As the section is rectangular with different depth and width values, the tower has one weak direction. Here the depth is 40 cm and the width is 45 cm. This means that the first critical buckling load is expected to be about 8.6e4N in the depth direction (y direction). In the width direction, which is expected to be stiffer, the critical buckling load is estimated to be about 1.1e5N.

The results obtained with the linear buckling analysis agree well with these values. Note that the approximation given for the Euler buckling critical load is suitable for a tower structure when the height is significantly larger than the width or the depth.

Figure 2 shows the value of the first critical buckling load and the deformation shape.

Critical load factor=84820




Figure 2: Deformation shape at the first critical buckling load

[Figure 3](#) shows the value of the second critical buckling load and the deformation shape.

Critical load factor=1.072E5




Figure 3: Deformation shape at the second critical buckling load

The plot of the force in post buckling analysis ([Figure 4](#)) shows that the higher forces are located at the base of the tower, while the points at the top of the tower have the maximum horizontal displacement. The displacement plot shows a sudden increase around the critical load, see [Figure 5](#). The stress plot ([Figure 6](#)) shows a sudden increase of the stress at critical load. The stress value become very high, probably higher than the physical limits of the material, which may cause a total collapse of the structure.

load(15)=84820 N

Line: Local axial force (N)




Figure 4: Force in truss at critical load




Figure 5: Displacement of the top of the tower in post buckling study




Figure 6: Stress in the truss at critical load

Notes About the COMSOL Implementation

The settings of the post buckling analysis are made easier by the **Buckling Imperfection** node.

It contains a **Deformed Geometry** section that enables to choose the buckling solution and modes that will define the prescribed displacements. The **Create** button generates one **Prescribed Deformation** node for each structural mechanics physics interface involved, and sets the prescribed deformations with the variables defined by the node. The prescribed deformations are those computed in the linear buckling study, multiplied by the scale factor. Low values of scale factor make the buckling effect sharper, but lead to more difficult convergence.

The **Nonlinear Buckling Study** section enables to select an existing study or choose to create a new one, and choose a parameter used to increase the loads in an auxiliary sweep. The **Create** button then creates a new stationary study if required, then checks **Include geometric nonlinearities** on, and applies an auxiliary sweep with the selected parameter. The

parameters values are filled based on the calculated critical buckling factor, with a logarithmic increase to capture accurately the behavior near the singularity.

Application Library path: Structural_Mechanics_Module/
Buckling_and_Wrinkling/truss_tower_buckling

Modeling Instructions

From the **File** menu, choose **New**.

NEW

In the **New** window, click  **Model Wizard**.

MODEL WIZARD

- 1 In the **Model Wizard** window, click  **3D**.
- 2 In the **Select Physics** tree, select **Structural Mechanics>Truss (truss)**.
- 3 Click **Add**.
- 4 Click  **Study**.
- 5 In the **Select Study** tree, select **Preset Studies for Selected Physics Interfaces>Linear Buckling**.
- 6 Click  **Done**.

GLOBAL DEFINITIONS

Geometric Parameters

- 1 In the **Model Builder** window, under **Global Definitions** click **Parameters 1**.
- 2 In the **Settings** window for **Parameters**, type **Geometric Parameters** in the **Label** text field.
- 3 Locate the **Parameters** section. Click  **Load from File**.
- 4 Browse to the model's Application Libraries folder and double-click the file **truss_tower_buckling_geometric_parameters.txt**.

Loads

- 1 In the **Home** toolbar, click  **Parameters** and choose **Add>Parameters**.
- 2 In the **Settings** window for **Parameters**, type **Loads** in the **Label** text field.

3 Locate the **Parameters** section. In the table, enter the following settings:

Name	Expression	Value	Description
I1	$4*A1*(\text{depth}/2)^2$	6.2832E-5 m ⁴	Area moment of inertia weak direction
Fc1	$\pi^2*200e9[\text{Pa}]*I1/(2*L)^2$	85890 N	First critical buckling load
I2	$4*A1*(\text{width}/2)^2$	7.9522E-5 m ⁴	Area moment of inertia stiffer direction
Fc2	$\pi^2*200e9[\text{Pa}]*I2/(2*L)^2$	1.087E5 N	Second critical buckling load
load	1[N]	1 N	Applied load

GEOMETRY I

Block 1 (blk1)

- 1 In the **Geometry** toolbar, click  **Block**.
- 2 In the **Settings** window for **Block**, locate the **Size and Shape** section.
- 3 In the **Width** text field, type **width**.
- 4 In the **Depth** text field, type **depth**.
- 5 In the **Height** text field, type **height**.

Polygon 1 (pol1)

- 1 In the **Geometry** toolbar, click  **More Primitives** and choose **Polygon**.
- 2 In the **Settings** window for **Polygon**, locate the **Object Type** section.
- 3 From the **Type** list, choose **Closed curve**.
- 4 Locate the **Coordinates** section. In the table, enter the following settings:

x (m)	y (m)	z (m)
0	depth	0
0	0	height
width	0	0
width	depth	height

Line Segment 1 (ls1)

- 1 In the **Geometry** toolbar, click  **More Primitives** and choose **Line Segment**.
- 2 In the **Settings** window for **Line Segment**, locate the **Starting Point** section.
- 3 From the **Specify** list, choose **Coordinates**.

4 Locate the **Endpoint** section. From the **Specify** list, choose **Coordinates**.

5 Locate the **Starting Point** section. In the **y** text field, type **depth**.

6 Locate the **Endpoint** section. In the **x** text field, type **width**.

Line Segment 2 (ls2)

1 In the **Geometry** toolbar, click  **More Primitives** and choose **Line Segment**.

2 In the **Settings** window for **Line Segment**, locate the **Starting Point** section.

3 From the **Specify** list, choose **Coordinates**.

4 Locate the **Endpoint** section. From the **Specify** list, choose **Coordinates**.

5 Locate the **Starting Point** section. In the **z** text field, type **height**.


6 Locate the **Endpoint** section. In the **x** text field, type **width**, **y** to **depth**, and **z** to **height**.

Convert to Curve 1 (ccurl1)

1 In the **Geometry** toolbar, click  **Conversions** and choose **Convert to Curve**.

2 Click in the **Graphics** window and then press **Ctrl+A** to select all objects.


3 In the **Geometry** toolbar, click  **Build All**.



Mirror 1 (mir1)

1 In the **Geometry** toolbar, click  **Transforms** and choose **Mirror**.

- 2 Select the object **ccur1** only.
- 3 In the **Settings** window for **Mirror**, locate the **Input** section.
- 4 Select the **Keep input objects** check box.
- 5 Locate the **Point on Plane of Reflection** section. In the **z** text field, type **height**.
- 6 In the **Geometry** toolbar, click  **Build All**.



Array 1 (arr1)

- 1 In the **Geometry** toolbar, click  **Transforms** and choose **Array**.
- 2 Select the object **ccur1** only.
- 3 In the **Settings** window for **Array**, locate the **Size** section.
- 4 In the **z size** text field, type **n**.
- 5 Locate the **Displacement** section. In the **z** text field, type **2*height**.


Array 2 (arr2)

- 1 In the **Geometry** toolbar, click  **Transforms** and choose **Array**.
- 2 Select the object **mir1** only.
- 3 In the **Settings** window for **Array**, locate the **Size** section.
- 4 In the **z size** text field, type **n-1**.

5 Locate the **Displacement** section. In the **z** text field, type `2*height`.

6 In the **Geometry** toolbar, click  **Build All**.

7 Click the  **Go to Default View** button in the **Graphics** toolbar.



Create selections for vertical and transversal edges to make further modeling easier.

DEFINITIONS

Vertical Edges


1 In the **Definitions** toolbar, click  **Explicit**.

2 In the **Settings** window for **Explicit**, type `Vertical Edges` in the **Label** text field.

3 Locate the **Input Entities** section. From the **Geometric entity level** list, choose **Edge**.

4 Select Edges 1, 108, 176, and 234 only.


5 Select the **Group by continuous tangent** check box.



Transversal Edges

- 1 In the **Definitions** toolbar, click **Complement**.
- 2 In the **Settings** window for **Complement**, type **Transversal Edges** in the **Label** text field.
- 3 Locate the **Geometric Entity Level** section. From the **Level** list, choose **Edge**.
- 4 Locate the **Input Entities** section. Under **Selections to invert**, click **Add**.
- 5 In the **Add** dialog box, select **Vertical Edges** in the **Selections to invert** list.

6 Click **OK**.



ADD MATERIAL

- 1 In the **Home** toolbar, click  **Add Material** to open the **Add Material** window.
- 2 Go to the **Add Material** window.
- 3 In the tree, select **Built-in>Structural steel**.
- 4 Click **Add to Component** in the window toolbar.
- 5 In the **Home** toolbar, click  **Add Material** to close the **Add Material** window.

TRUSS (TRUSS)

Cross-Section Data 1

- 1 In the **Model Builder** window, under **Component 1 (comp1)>Truss (truss)** click **Cross-Section Data 1**.
- 2 In the **Settings** window for **Cross-Section Data**, locate the **Cross-Section Data** section.
- 3 In the **A** text field, type **A1**.

Cross-Section Data 2

- 1 In the **Physics** toolbar, click  **Edges** and choose **Cross-Section Data**.
- 2 In the **Settings** window for **Cross-Section Data**, locate the **Edge Selection** section.

- 3 From the **Selection** list, choose **Transversal Edges**.
- 4 Locate the **Cross-Section Data** section. In the **A** text field, type **A2**.

Pinned /

- 1 In the **Physics** toolbar, click  **Points** and choose **Pinned**.
- 2 In the **Settings** window for **Pinned**, locate the **Point Selection** section.
- 3 Click  **Paste Selection**.
- 4 In the **Paste Selection** dialog box, type **1 21 41 61** in the **Selection** text field.
- 5 Click **OK**.

Point Load /

- 1 In the **Physics** toolbar, click  **Points** and choose **Point Load**.
- 2 In the **Settings** window for **Point Load**, locate the **Point Selection** section.
- 3 Click  **Paste Selection**.
- 4 In the **Paste Selection** dialog box, type **20 40 60 80** in the **Selection** text field.
- 5 Click **OK**.
- 6 In the **Settings** window for **Point Load**, locate the **Force** section.
- 7 Specify the \mathbf{F}_P vector as

0	x
0	y
-load/4	z

STUDY 1

Step 2: Linear Buckling

- 1 In the **Model Builder** window, under **Study 1** click **Step 2: Linear Buckling**.
- 2 In the **Settings** window for **Linear Buckling**, locate the **Study Settings** section.
- 3 In the **Desired number of buckling modes** text field, type **2**.
- 4 In the **Home** toolbar, click  **Compute**.

RESULTS

Line 1

- 1 In the **Model Builder** window, expand the **Mode Shape (truss)** node, then click **Line 1**.
- 2 In the **Settings** window for **Line**, click to expand the **Title** section.

- 3 From the **Title type** list, choose **None**.
- 4 Locate the **Coloring and Style** section. In the **Radius scale factor** text field, type 4.
- 5 Click the  **Show Grid** button in the **Graphics** toolbar.
- 6 In the **Mode Shape (truss)** toolbar, click  **Plot**.

Now prescribe a deformation to the geometry from the calculated buckling mode to perform a post-buckling study.

DEFINITIONS

Buckling Imperfection 1 (bck1)

- 1 In the **Definitions** toolbar, click  **Physics Utilities** and choose **Buckling Imperfection**.
- 2 In the **Settings** window for **Buckling Imperfection**, locate the **Deformed Geometry** section.
- 3 Find the **Mode selection** subsection. In the table, enter the following settings:

Mode	Scale factor
1	1e3

- 4 Click **Create** in the upper-right corner of the **Deformed Geometry** section.

This button creates a **Prescribed Deformation** node with the requested deformation settings. The newly created **Prescribed Deformation** is automatically disabled in the existing study steps to enable further computation without changes in the results.

- 5 Locate the **Nonlinear Buckling Study** section. From the **Load parameter** list, choose **load (Applied load)**.

- 6 Click **Create** in the upper-right corner of the **Nonlinear Buckling Study** section.

This button creates a new study with stationary step, activates geometric nonlinearities and applies an auxiliary sweep for the post-buckling study.

STUDY 2

Solution 3 (sol3)

- 1 In the **Model Builder** window, expand the **Component 1 (comp1)>Deformed Geometry** node.
- 2 Right-click **Study 2** and choose **Show Default Solver**.
- 3 In the **Model Builder** window, expand the **Solution 3 (sol3)** node.
- 4 In the **Model Builder** window, expand the **Study 2>Solver Configurations>Solution 3 (sol3)>Stationary Solver 1** node, then click **Fully Coupled 1**.

- 5 In the **Settings** window for **Fully Coupled**, click to expand the **Method and Termination** section.
- 6 From the **Nonlinear method** list, choose **Constant (Newton)**.
- 7 In the **Study** toolbar, click  **Compute**.

RESULTS

Force (truss)

- 1 In the **Settings** window for **3D Plot Group**, locate the **Data** section.
- 2 From the **Parameter value (load (N))** list, choose **84820**.

Line 1

- 1 In the **Model Builder** window, expand the **Force (truss)** node, then click **Line 1**.
- 2 In the **Settings** window for **Line**, locate the **Coloring and Style** section.
- 3 In the **Radius scale factor** text field, type 4.
- 4 In the **Force (truss)** toolbar, click  **Plot**.

Stress (truss)

- 1 In the **Model Builder** window, under **Results** click **Stress (truss)**.
- 2 In the **Settings** window for **3D Plot Group**, locate the **Data** section.
- 3 From the **Parameter value (load (N))** list, choose **84820**.

Line 1

- 1 In the **Model Builder** window, expand the **Stress (truss)** node, then click **Line 1**.
- 2 In the **Settings** window for **Line**, locate the **Coloring and Style** section.
- 3 In the **Radius scale factor** text field, type 4.
- 4 Locate the **Expression** section. From the **Unit** list, choose **MPa**.
- 5 In the **Stress (truss)** toolbar, click  **Plot**.

Create a new plot to show the displacement with respect to applied load.

Post Buckling Displacement

- 1 In the **Home** toolbar, click  **Add Plot Group** and choose **ID Plot Group**.
- 2 In the **Settings** window for **ID Plot Group**, locate the **Data** section.
- 3 From the **Dataset** list, choose **Study 2/Solution 3 (sol3)**.
- 4 In the **Label** text field, type **Post Buckling Displacement**.

Point Graph 1

- 1 Right-click **Post Buckling Displacement** and choose **Point Graph**.
- 2 Select Point 20 only.
- 3 In the **Settings** window for **Point Graph**, locate the **y-Axis Data** section.
- 4 In the **Expression** text field, type v .
- 5 Click to expand the **Coloring and Style** section. Find the **Line markers** subsection. From the **Marker** list, choose **Point**.
- 6 From the **Positioning** list, choose **In data points**.
- 7 In the **Post Buckling Displacement** toolbar, click  **Plot**.

Post Buckling Stress

- 1 In the **Model Builder** window, right-click **Post Buckling Displacement** and choose **Duplicate**.
- 2 In the **Settings** window for **ID Plot Group**, type Post Buckling Stress in the **Label** text field.

Point Graph 1

- 1 In the **Model Builder** window, expand the **Post Buckling Stress** node, then click **Point Graph 1**.
- 2 In the **Settings** window for **Point Graph**, locate the **Selection** section.
- 3 Click  **Clear Selection**.
- 4 Select Point 1 only.
- 5 Click **Replace Expression** in the upper-right corner of the **y-Axis Data** section. From the menu, choose **Component 1 (compl1)>Truss>Stress>truss.mises - von Mises stress - N/m²**.
- 6 Locate the **y-Axis Data** section. From the **Unit** list, choose **MPa**.
- 7 In the **Post Buckling Stress** toolbar, click  **Plot**.

