

Magnetic Field from an Infinite Conductor

This introduction model creates a simple model of the magnetostatics problem with a coaxial cable of infinite length carrying current, which is commonly found in textbooks. Since there is an analytical solution to this problem, the model can be used to compare theory with numerical results from the simulation. The region outside of the coaxial cable is not part of this model.

Model Definition

First, consider the analytical solution to this problem, which can be used for comparison. Let r_i and r_o be the radii of the inner and outer conductors, respectively. In this case, the latter is also equivalent to the radius of the modeling domain. In the air region between the two conductors, — that is, for $r_i < r < r_o$ — the magnetic flux density, **B**, satisfies

$$\mathbf{B} = \frac{\mu_0 I_0}{2\pi r} \hat{\mathbf{\phi}}$$

where μ_0 is the permeability of vacuum, I_0 is the current through the conductor, and φ is a unit vector in the azimuthal direction. Inside the center conductor, where $r < r_i$, the solution instead reads

$$\mathbf{B} = \frac{\mu_0 J_0 r}{2} \hat{\mathbf{\phi}}$$

where J_0 is the current density. These expressions can, for example, be derived by using the integral formulation of Ampère's law. From the symmetry of the problem it follows that the magnetic field is orientated purely in the azimuthal direction and that its strength depends only on the radial distance from the conductor.

The geometry of the conductor will be created in two different ways:

- By using a 2D component, where the Magnetic Fields interface solves for the out-ofplane magnetic vector potential. The 2D component then corresponds to the cross section of the infinite conductor.
- By using a 2D axisymmetric component, where the Magnetic and Electric Fields interface solves for the in-plane magnetic vector potential as well as the electric potential. This component, when revolved around the axis, represents the full conductor.

Even though the outer conductor of the coaxial cable is seemingly not part of the model geometry, which only contains the inner conductor and an air domain, the return currents are still present in the model. This is achieved by using the Magnetic Insulation boundary condition, which is the default boundary condition in the Magnetic and Electric Fields physics interface. This condition applies the constraint $\mathbf{n} \times \mathbf{A} = 0$, where \mathbf{A} is the magnetic vector potential. Current can therefore flow along this boundary, and as shown in Figure 5, the current forms a closed loop through the inner conductor.

Results

The magnetic flux density norm in the 2D component is plotted in Figure 1, while the magnetic flux density norm in the 2D axisymmetric component is shown in Figure 2 (symmetry cross section) and Figure 3 (revolved geometry). Figure 4 shows a plot of the magnetic flux density as a function of the radial coordinate for the two numerical solutions as well as for the analytical solution discussed above. There, it can be seen how well the numerical solutions corresponding to the two different approaches agree with the analytical solution. Finally, Figure 5 shows the return currents along the outside of the air domain in the 2D axisymmetric case.




Figure 1: Magnetic flux density norm in the 2D component.




Figure 2: Magnetic flux density norm in the 2D axisymmetric component.




Figure 3: Magnetic flux density norm in the 2D axisymmetric component, shown in the full revolved geometry.




Figure 4: The magnetic flux density norm plotted as a function of the radial coordinate. Here, the numerical solutions from the two different components are shown, along with the analytical solution.




Figure 5: The surface currents plotted on the outside of the modeling domain, along with the currents and the electric potential in the inner conductor.

Application Library path: ACDC_Module/Introductory_Magnetostatics/magnetic_field_infinite_conductor

Modeling Instructions

From the File menu, choose New.

NEW

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click **Q** 2D.
- 2 In the Select Physics tree, select AC/DC>Electromagnetic Fields>Magnetic Fields (mf).
- 3 Click Add.
- 4 Click 🔵 Study.

- 5 In the Select Study tree, select General Studies>Stationary.
- 6 Click **Done**.

First, define some parameters that will be used when building the model.

GLOBAL DEFINITIONS

Parameters 1

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- **3** In the table, enter the following settings:

Name	Expression	Value	Description
ri	1[cm]	0.01 m	Radius of the conductor
ro	10[cm]	0.1 m	Radius of the computation domain
10	1[A]	ΙA	Conducting current
J0	I0/(pi*ri^2)	3183.1 A/m ²	Current density in the conductor

GEOMETRY I

One way of constructing the geometry is to use a 2D component. Since the Magnetic Fields physics interface by default only solves for the out-of-plane component of the magnetic vector potential, this is equivalent to having a conductor of infinite length, where the 2D geometry corresponds to the cross section.

Circle I (c1)

- I In the Model Builder window, expand the Component I (compl)>Geometry I node.
- 2 Right-click Geometry I and choose Circle.
- 3 In the Settings window for Circle, locate the Size and Shape section.
- 4 In the Radius text field, type ro.
- **5** Click to expand the **Layers** section. In the table, enter the following settings:

Layer name	Thickness (m)
Layer 1	ro-ri

Point I (pt I)

In the **Geometry** toolbar, click • **Point**.

Line Segment I (Is I)

- I In the Geometry toolbar, click * More Primitives and choose Line Segment.
- 2 On the object pt1, select Point 1 only.
- 3 In the Settings window for Line Segment, locate the Endpoint section.
- 4 Find the End vertex subsection. Click to select the Activate Selection toggle button.
- **5** On the object **c1**, select Point 7 only.
- 6 In the Geometry toolbar, click **Build All**.

MATERIALS

Air

- I In the Model Builder window, under Component I (compl) right-click Materials and choose Blank Material.
- 2 In the Settings window for Material, type Air in the Label text field.
- **3** Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Relative permeability	mur_iso; murii = mur_iso, murij = 0	1	I	Basic
Electrical conductivity	sigma_iso; sigmaii = sigma_iso, sigmaij = 0	0	S/m	Basic
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	1	I	Basic

Conductor

- I Right-click Air and choose Duplicate.
- 2 In the Settings window for Material, type Conductor in the Label text field.
- **3** Select Domain 4 only.

4 Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Electrical conductivity	sigma_iso; sigmaii = sigma_iso, sigmaij = 0	1e6	S/m	Basic

The only modification that needs to be done for the physics, is adding a current density.

MAGNETIC FIELDS (MF)

External Current Density I

- I In the Model Builder window, under Component I (compl) right-click Magnetic Fields (mf) and choose External Current Density.
- 2 Select Domain 4 only.
- 3 In the Settings window for External Current Density, locate the External Current Density section.
- **4** Specify the J_{e} vector as

0	x
0	у
J0	z

STUDY I

In the **Home** toolbar, click **Compute**.

Now, add a second, 2D axisymmetric, component that will be used to illustrate a different approach to modeling the same problem. It will contain an equivalent geometry and the same materials.

ADD COMPONENT

In the Model Builder window, right-click the root node and choose Add Component> 2D Axisymmetric.

GEOMETRY 2

Rectangle I (rI)

I In the Geometry toolbar, click Rectangle.

- 2 In the Settings window for Rectangle, locate the Size and Shape section.
- 3 In the Width text field, type ro.
- 4 In the Height text field, type 2*ro.
- **5** Click to expand the **Layers** section. In the table, enter the following settings:

Layer name	Thickness (m)			
Layer 1	ri			

- 6 Select the Layers to the left check box.
- 7 Clear the Layers on bottom check box.
- 8 In the Geometry toolbar, click **Build All**.

ADD PHYSICS

- I In the Home toolbar, click Add Physics to open the Add Physics window.
- 2 Go to the Add Physics window.
- 3 In the tree, select AC/DC>Electromagnetic Fields>Vector Formulations> Magnetic and Electric Fields (mef).
- 4 Click Add to Component 2 in the window toolbar.

MATERIALS

Air

- I In the Model Builder window, under Component 2 (comp2) right-click Materials and choose Blank Material.
- 2 In the Settings window for Material, type Air in the Label text field.
- **3** Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Relative permeability	mur_iso; murii = mur_iso, murij = 0	1	ı	Basic

Property	Variable	Value	Unit	Property group
Electrical conductivity	sigma_iso; sigmaii = sigma_iso, sigmaij = 0	0	S/m	Basic
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	1	I	Basic

Conductor

- I Right-click Air and choose Duplicate.
- 2 In the Settings window for Material, type Conductor in the Label text field.
- **3** Select Domain 1 only.
- **4** Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Electrical conductivity	sigma_iso; sigmaii = sigma_iso, sigmaij = 0	1e6	S/m	Basic

In the Magnetic and Electric Fields physics interface, we will solve for the in-plane magnetic vector potential, and use the Terminal feature to excite the conductor.

MAGNETIC AND ELECTRIC FIELDS (MEF)

- I In the Model Builder window, under Component 2 (comp2) click Magnetic and Electric Fields (mef).
- 2 In the Settings window for Magnetic and Electric Fields, locate the Components section.
- 3 From the Field components solved for list, choose In-plane vector potential.

MAGNETIC AND ELECTRIC FIELDS (MEF)

Magnetic Insulation 1

In the Model Builder window, expand the Component I (compl)>Magnetic Fields (mf)> Magnetic Insulation I node, then click Component 2 (comp2)> Magnetic and Electric Fields (mef)>Magnetic Insulation 1.

Terminal I

- I In the Physics toolbar, click Attributes and choose Terminal.
- 2 Select Boundary 3 only.
- 3 In the Settings window for Terminal, locate the Terminal section.
- **4** In the I_0 text field, type 10.

Finally, add an Ampère's law feature to the air domain, since we do not need to solve for the electric potential there. Also, add a Gauge Fixing for A-field feature. This was not needed in the component where only the out-of-plane vector potential component is solved for, since that setting acts as an inherent gauge fix.

Ambère's Law I

- In the Physics toolbar, click **Domains** and choose Ampère's Law.
- 2 Select Domain 2 only.

Gauge Fixing for A-field I

In the Physics toolbar, click **Domains** and choose **Gauge Fixing for A-field**.

Now, add a another stationary study for the second component, and make sure that the two studies only solve for their respective physics interfaces.

STUDY I

Step 1: Stationary

- I In the Model Builder window, under Study I click Step I: Stationary.
- 2 In the Settings window for Stationary, locate the Physics and Variables Selection section.
- **3** In the table, enter the following settings:

Physics interface	Solve for	Equation form	
Magnetic Fields (mf)	\checkmark	Automatic (Stationary)	
Magnetic and Electric Fields (mef)		Automatic (Stationary)	

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select General Studies>Stationary.
- 4 Click Add Study in the window toolbar.

STUDY 2

Step 1: Stationary

- I In the Settings window for Stationary, locate the Physics and Variables Selection section.
- **2** In the table, enter the following settings:

Physics interface	Solve for	Equation form
Magnetic Fields (mf)		Automatic (Stationary)
Magnetic and Electric Fields (mef)	V	Automatic (Stationary)

3 In the Home toolbar, click **Compute**.

Now, it is time to compare the results with the known analytical solutions. Add plots of the magnetic flux density computed from each component, as well as a plot containing the known analytical solution to the problem. Note that the solution is different in the regions inside and outside of the conductor.

RESULTS

Magnetic Flux Density Comparison

- I In the Home toolbar, click Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Magnetic Flux Density Comparison in the Label text field.
- 3 Click to expand the Title section. From the Title type list, choose Label.
- 4 Locate the Data section. From the Dataset list, choose None.

Line Graph 1

- I Right-click Magnetic Flux Density Comparison and choose Line Graph.
- 2 In the Settings window for Line Graph, locate the Data section.
- 3 From the Dataset list, choose Study I/Solution I (soll).
- 4 Select Boundaries 3 and 5 only.
- 5 Locate the x-Axis Data section. From the Parameter list, choose Expression.
- **6** In the **Expression** text field, type x.
- 7 Click to expand the **Legends** section. Select the **Show legends** check box.
- **8** Find the **Include** subsection. Clear the **Solution** check box.
- **9** Select the **Description** check box.
- 10 Find the Prefix and suffix subsection. In the Suffix text field, type, component 1.

- II Click to expand the Coloring and Style section. Find the Line markers subsection. From the Marker list, choose Cycle.
- **12** From the **Positioning** list, choose **Interpolated**.

Magnetic Flux Density Comparison

- I In the Model Builder window, click Magnetic Flux Density Comparison.
- 2 In the Settings window for ID Plot Group, locate the Plot Settings section.
- 3 Select the x-axis label check box. In the associated text field, type r-coordinate (m).
- 4 Select the y-axis label check box. In the associated text field, type Magnetic Flux Density Norm (T).

Line Grabh 2

- I Right-click Magnetic Flux Density Comparison and choose Line Graph.
- 2 In the Settings window for Line Graph, locate the Data section.
- 3 From the Dataset list, choose Study 2/Solution 2 (3) (sol2).
- **4** Select Boundaries 2 and 5 only.
- 5 Locate the y-Axis Data section. In the Expression text field, type mef.normB.
- 6 Locate the x-Axis Data section. From the Parameter list, choose Expression.
- 7 In the **Expression** text field, type r.
- **8** Locate the **Legends** section. Select the **Show legends** check box.
- **9** Find the **Include** subsection. Clear the **Solution** check box.
- **10** Select the **Description** check box.
- II Find the Prefix and suffix subsection. In the Suffix text field, type, component 2.
- 12 Locate the Coloring and Style section. Find the Line markers subsection. From the Marker list, choose Cycle.
- 13 From the Positioning list, choose Interpolated.

Line Graph 3

- I Right-click Magnetic Flux Density Comparison and choose Line Graph.
- 2 In the Settings window for Line Graph, locate the Data section.
- 3 From the Dataset list, choose Study 2/Solution 2 (3) (sol2).
- **4** Select Boundaries 2 and 5 only.
- 5 Locate the y-Axis Data section. In the Expression text field, type mu0 const*J0/2*r* (r<=ri)+mu0_const*I0/(2*pi*r)*(r>ri).
- **6** Locate the **Legends** section. Select the **Show legends** check box.

- 7 Find the **Include** subsection. Clear the **Solution** check box.
- **8** Select the **Expression** check box.
- **9** From the Legends list, choose Manual.
- **10** In the table, enter the following settings:

Legends

Analytical solution

II In the Magnetic Flux Density Comparison toolbar, click **Plot**.

As the last step, create a plot which illustrates the return currents on the outside of the air domain.

Air Domain Return Current (mef)

- I In the Home toolbar, click **Add Plot Group** and choose **3D Plot Group**.
- 2 In the Settings window for 3D Plot Group, type Air Domain Return Current (mef) in the Label text field.

Arrow Surface 1

- I Right-click Air Domain Return Current (mef) and choose Arrow Surface.
- 2 In the Settings window for Arrow Surface, click Replace Expression in the upper-right corner of the Expression section. From the menu, choose Component 2 (comp2)> Magnetic and Electric Fields>Currents and charge>mef.|sr,...,mef.|sz -Surface current density.
- 3 Locate the Arrow Positioning section. In the Number of arrows text field, type 1500.
- 4 Locate the Coloring and Style section.
- **5** Select the **Scale factor** check box. In the associated text field, type 0.002.
- **6** From the **Color** list, choose **Black**.
- 7 In the Air Domain Return Current (mef) toolbar, click Plot.

Arrow Surface 2

- I In the Model Builder window, right-click Air Domain Return Current (mef) and choose Arrow Surface.
- 2 In the Settings window for Arrow Surface, locate the Expression section.
- 3 In the **r-component** text field, type mef.Jr/(dom==1).
- 4 In the phi-component text field, type mef.Jphi/(dom==1).
- 5 In the z-component text field, type mef.Jz/(dom==1).

- 6 Locate the Arrow Positioning section. In the Number of arrows text field, type 3000.
- 7 Locate the Coloring and Style section.
- 8 Select the Scale factor check box. In the associated text field, type 4e-6.
- 9 From the Color list, choose Black.
- 10 Click to expand the Title section. From the Title type list, choose None.

Volume 1

- I Right-click Air Domain Return Current (mef) and choose Volume.
- 2 In the Settings window for Volume, click to expand the Title section.
- 3 From the Title type list, choose Manual.
- 4 In the Title text area, type Volume: Electric potential.
- 5 In the Air Domain Return Current (mef) toolbar, click Plot.