



Model created in COMSOL Multiphysics 6.4

Damping Coefficients of a Squeeze-Film Damper

Introduction

Squeeze-film dampers are components that provide additional damping to rotating machines. To simplify the modeling of a rotor assembly, squeeze-film dampers are often modeled in terms of their damping coefficients. This model computes damping coefficients for a short squeeze-film damper and compares them to analytically computed values. The damping coefficients depend on the journal location in the damper.

Model Definition

The cylindrical squeeze-film damper has a radius of 10 cm and length of 1 cm. The journal undergoes a circular whirl at 100 rpm, and the clearance between the journal and the damper bushing is 1 mm. The viscosity and density of the lubricant are taken as 20 mPa·s and 864 kg/m³, respectively. The relative eccentricity of the journal is varied from 0.02 to 0.96 in the steps of 0.02. The attitude angle is specified relative to the static load on the damper at $\phi = 10^\circ$. The damping coefficients are computed for all eccentricity values by solving a perturbed form of Reynolds equation.

The local directions of the damper are aligned with the global y and z directions, with the negative z direction defining $\phi = 0^\circ$. The attitude angle of the journal measured from the local y direction is therefore $\theta = 3\pi/2 + \phi$. The coordinates of the journal location in the damper, in local directions, are given by

$$\mathbf{u}_J = \begin{Bmatrix} 0 \\ C\varepsilon \cos \theta \\ C\varepsilon \sin \theta \end{Bmatrix} = \begin{Bmatrix} 0 \\ C\varepsilon \sin \phi \\ -C\varepsilon \cos \phi \end{Bmatrix}$$

where C is the clearance and ε is the relative eccentricity of the journal. Analytical values for the radial and tangential dimensionless damping coefficients (Ref. 1) are given by

$$c_{rr} = c_0 \left(\frac{\pi(1+2\varepsilon^2)}{2(1-\varepsilon^2)^{5/2}} \right)$$

$$c_{rt} = c_0 \left(\frac{2\varepsilon}{(1-\varepsilon^2)^2} \right)$$

$$c_{tr} = c_{rt}$$

$$c_{tt} = c_0 \left(\frac{\pi}{2(1-\varepsilon^2)^{3/2}} \right)$$

where c_0 is a dimensional scaling factor for the damping coefficients. This is given by

$$c_0 = \mu R \left(\frac{L}{C} \right)^3$$

The damping coefficients are transformed from global to local coordinates as

$$\begin{bmatrix} c_{22} & c_{23} \\ c_{32} & c_{33} \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta \\ \sin \theta & \cos \theta \end{bmatrix} \begin{bmatrix} c_{rr} & c_{rt} \\ c_{tr} & c_{tt} \end{bmatrix} \begin{bmatrix} \cos \theta & -\sin \theta \\ \sin \theta & \cos \theta \end{bmatrix}^T$$

Results and Discussion

Figure 1 shows the various components of the computed damping coefficients and compares them to their analytical counterparts. The computed values match the analytical values.




Figure 1: Damping coefficients.

Reference


1. W.J. Chen and E.J. Gunter, *Introduction to the Dynamics of Rotor-Bearing Systems*, sections 6.10 and 6.11, pp. 263–271, Trafford Publishing, 2007.

Application Library path: Rotordynamics_Module/Verification_Examples/
squeeze_film_damper_damping_coefficients




Modeling Instructions

From the **File** menu, choose **New**.

NEW

In the **New** window, click  **Model Wizard**.

MODEL WIZARD

- 1 In the **Model Wizard** window, click  **3D**.
- 2 In the **Select Physics** tree, select **Structural Mechanics > Rotordynamics > Hydrodynamic Bearing (hdb)**.
- 3 Click **Add**.
- 4 Click  **Study**.
- 5 In the **Select Study** tree, select **General Studies > Stationary**.
- 6 Click  **Done**.

Create the parameters for the damper and lubricants properties.

GLOBAL DEFINITIONS

Parameters 1



- 1 In the **Model Builder** window, under **Global Definitions** click **Parameters 1**.
- 2 In the **Settings** window for **Parameters**, locate the **Parameters** section.
- 3 In the table, enter the following settings:

Name	Expression	Value	Description
fr	100[rpm]	1.6667 1/s	Whirl speed
R	10[cm]	0.1 m	Journal radius
L	1[cm]	0.01 m	Journal length
C	1000[um]	0.001 m	Clearance
e	0	0	Eccentricity
phi	10[deg]	0.17453 rad	Attitude angle

Name	Expression	Value	Description
mu0	20[mPa*s]	0.02 Pa·s	Oil viscosity
rho0	864[kg/m^3]	864 kg/m ³	Oil density

GEOMETRY I

Cylinder 1 (cyl1)

- 1 In the **Geometry** toolbar, click  **Cylinder**.
- 2 In the **Settings** window for **Cylinder**, locate the **Size and Shape** section.
- 3 In the **Radius** text field, type R.
- 4 In the **Height** text field, type L.
- 5 Locate the **Axis** section. From the **Axis type** list, choose **x-axis**.
- 6 Locate the **Object Type** section. From the **Type** list, choose **Surface**.
- 7 Click  **Build Selected**.

Define the variables for the analytical damping coefficients in local *y* and *z* directions.

DEFINITIONS

Variables 1

- 1 In the **Model Builder** window, under **Component 1 (comp1)** right-click **Definitions** and choose **Variables**.
- 2 In the **Settings** window for **Variables**, locate the **Variables** section.
- 3 In the table, enter the following settings:


Name	Expression	Unit	Description
c0	$\mu_0 R^3 (L/C)^3$	kg/s	Damping scaling
c_rr	$\frac{\pi(1+2e^2)}{(2(1-e^2)^{2.5})}$		Damping coefficient, rr component
c_rt	$2e/(1-e^2)^2$		Damping coefficient, rt component
c_tr	c_rt		Damping coefficient, tr component
c_tt	$\frac{\pi}{2(1-e^2)^{1.5}}$		Damping coefficient, tt component
c_22	$c_{rr}(\sin(\phi))^2 + c_{rt} \sin(2\phi) + c_{tt}(\cos(\phi))^2$		Damping coefficient, 22 component

Name	Expression	Unit	Description
c_23	$(-c_{rr}+c_{tt})\sin(\phi)\cos(\phi)-c_{rt}\cos(2\phi)$		Damping coefficient, 23 component
c_32	c_23		Damping coefficient, 32 component
c_33	$c_{rr}(\cos(\phi))^2-c_{rt}\sin(2\phi)+c_{tt}(\sin(\phi))^2$		Damping coefficient, 33 component

HYDRODYNAMIC BEARING (HDB)

- 1 In the **Model Builder** window, under **Component 1 (comp1)** click **Hydrodynamic Bearing (hdb)**.
- 2 In the **Settings** window for **Hydrodynamic Bearing**, locate the **Dynamic Coefficients** section.
- 3 Select the **Calculate dynamic coefficients** checkbox.

Squeeze-Film Damper 1

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Squeeze-Film Damper**.
- 2 In the **Settings** window for **Squeeze-Film Damper**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **All boundaries**.
- 4 Locate the **Damper Properties** section. In the C text field, type C .
- 5 From the X_c list, choose **From geometry**.
- 6 Locate the **Journal Properties** section. From the **Specify** list, choose **Eccentricity and direction**.
- 7 In the e text field, type $C*e$.
- 8 In the ϕ_y text field, type $270[\text{deg}]+\phi$.
- 9 In the ω text field, type $2*\pi[\text{rad}]*f_r$.
- 10 Locate the **Film Boundary Condition** section. From the **Film type** list, choose **Gümbel**.
- 11 Locate the **Fluid Properties** section. From the μ list, choose **User defined**. In the associated text field, type μ_0 .
- 12 From the ρ list, choose **User defined**. In the associated text field, type ρ_0 .

Use a mapped mesh to resolve the pressure.

MESH 1

Mapped 1


- 1 In the **Mesh** toolbar, click  **More Generators** and choose **Mapped**.

- 2 In the **Settings** window for **Mapped**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **All boundaries**.

Distribution 1


- 1 Right-click **Mapped 1** and choose **Distribution**.
- 2 Select Edges 1, 2, 4, and 6 only.
- 3 In the **Settings** window for **Distribution**, locate the **Distribution** section.
- 4 In the **Number of elements** text field, type 50.

Distribution 2

- 1 In the **Model Builder** window, right-click **Mapped 1** and choose **Distribution**.
- 2 Select Edge 3 only.
- 3 In the **Settings** window for **Distribution**, click  **Build All**.

STUDY 1

Step 1: Stationary

- 1 In the **Model Builder** window, under **Study 1** click **Step 1: Stationary**.
- 2 In the **Settings** window for **Stationary**, click to expand the **Study Extensions** section.
- 3 Select the **Auxiliary sweep** checkbox.
- 4 Click  **Add**.
- 5 In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
e (Eccentricity)	range(0.02, 0.02, 0.96)	

- 6 In the **Study** toolbar, click  **Compute**.


RESULTS

Fluid Pressure (hdb)

- 1 In the **Fluid Pressure (hdb)** toolbar, click  **Plot**.

Pressure in the damper is the default plot. Follow the below instructions to compare the computed and the analytical values of the damping for the damper as shown in [Figure 1](#).

Damping Coefficients

- 1 In the **Results** toolbar, click  **ID Plot Group**.
- 2 In the **Settings** window for **ID Plot Group**, type Damping Coefficients in the **Label** text field.

Global 1

- 1 Right-click **Damping Coefficients** and choose **Global**.
- 2 In the **Settings** window for **Global**, click **Replace Expression** in the upper-right corner of the **y-Axis Data** section. From the menu, choose **Component 1 (comp1) > Hydrodynamic Bearing > Dynamic coefficients > Translational damping coefficient - N*s/m > hdb.sfd1.c22 - Translational damping coefficient, 22-component**.
- 3 Locate the **y-Axis Data** section. In the table, enter the following settings:

Expression	Unit	Description
hdb.sfd1.c22	1	c_{22} , COMSOL
-hdb.sfd1.c23	1	$-c_{23}$, COMSOL
-hdb.sfd1.c32	1	$-c_{32}$, COMSOL
hdb.sfd1.c33	1	c_{33} , COMSOL

- 4 Click to expand the **Coloring and Style** section. From the **Width** list, choose **2**.

Global 2



- 1 In the **Model Builder** window, right-click **Damping Coefficients** and choose **Global**.
- 2 In the **Settings** window for **Global**, locate the **y-Axis Data** section.
- 3 In the table, enter the following settings:

Expression	Unit	Description
$c_{22} * c_0$		c_{22} , Analytical
$-c_{23} * c_0$		$-c_{23}$, Analytical
$-c_{32} * c_0$		$-c_{32}$, Analytical
$c_{33} * c_0$		c_{33} , Analytical

- 4 Locate the **Coloring and Style** section. Find the **Line style** subsection. From the **Line** list, choose **None**.
- 5 From the **Color** list, choose **Cycle (reset)**.
- 6 Find the **Line markers** subsection. From the **Marker** list, choose **Circle**.

Damping Coefficients

- 1 In the **Model Builder** window, click **Damping Coefficients**.
- 2 In the **Settings** window for **ID Plot Group**, locate the **Plot Settings** section.
- 3 Select the **x-axis label** checkbox. In the associated text field, type **Relative eccentricity (e)**.

- 4 Select the **y-axis label** checkbox. In the associated text field, type Damping coefficients (N*s/m).
- 5 Click to expand the **Title** section. From the **Title type** list, choose **None**.
- 6 Locate the **Legend** section. From the **Position** list, choose **Upper left**.
- 7 In the **Number of columns** text field, type 2.
- 8 Click the  **y-Axis Log Scale** button in the **Graphics** toolbar.
- 9 In the **Damping Coefficients** toolbar, click  **Plot**.