

Thermoelectric Leg

A thermocouple is made of two different conductors (legs) in contact with each other at one point (junction). When a temperature difference is established between the two legs, then a voltage is established across the junction. Therefore a thermocouple properly calibrated is a temperature sensor and can convert temperature gradients into electric currents. In this validation example, we verify the response of one leg when a current is passed through the device. A cooling effect, known as the Peltier effect, is expected.

Model Definition

The component is 1-by-1-by-6 mm, as shown in Figure 1. The core of the device, the thermoelectric part, is made of bismuth telluride (Bi₂Te₃). It is capped by two thin copper electrodes, 0.1 mm thick.




Figure 1: Thermoelectric leg geometry.

The material properties are available in COMSOL Multiphysics Material Library. However, since the properties for bismuth telluride slightly differ from these from the original benchmark, values from Ref. 1 are used in this application.

TABLE I: MATERIAL PROPERTIES FOR BISMUTH TELLURIDE.

Property	Value		
Thermal conductivity	I.6 W/(m·K)		
Density	7740 kg/m³		
Heat capacity at constant pressure	154.4 J/(kg·K)		
Electrical conductivity	1.1e5 S/m		
Relative permittivity	1		
Seebeck coefficient	2e-4 V/K		

In addition Seebeck coefficient for copper, 6.5·10⁻⁶ V/K, is also taken from Ref. 1.

The bottom electrode surface is held at 0°C while the top electrode and the lateral surfaces are thermally insulated.

The bottom electrode is electrically grounded at 0 V. The total inward electric current through the top electrode is 0.7 A. The lateral surfaces are electrically insulated.

Results and Discussion

The current circulating in the thermoelectric device is responsible for the cooling effect shown in Figure 2. The temperature field is in complete agreement with the results from Ref. 1.




Figure 2: Temperature field on the thermoelectric leg surface.

Figure 3 shows the isothermal surfaces and the heat flux which is in the same direction as the electric current (from the top to the bottom).




Figure 3: Isothermal surfaces and heat flux in the thermoelectric leg.

The top level electrode reaches an electric potential of around 49.1 mV due to the inward current density set on this boundary. This corresponds to the value presented in Ref. 1.




Figure 4: Electric potential in the thermoelectric leg.

Reference

1. M. Jaegle, Multiphysics Simulation of Thermoelectric Systems, "Modeling of Peltier-Cooling and Thermoelectric Generation," Proc. COMSOL Conf. 2008 Hannover, 2008.

Application Library path: Heat_Transfer_Module/Verification_Examples/ thermoelectric_leg

Modeling Instructions

From the File menu, choose New.

NEW

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click **3D**.
- 2 In the Select Physics tree, select Heat Transfer>Thermoelectric Effect.
- 3 Click Add.
- 4 Click Study.
- 5 In the Select Study tree, select General Studies>Stationary.
- 6 Click **Done**.

GEOMETRY I

- I In the Model Builder window, under Component I (compl) click Geometry I.
- 2 In the Settings window for Geometry, locate the Units section.
- 3 From the Length unit list, choose mm.

Block I (blk I)

- I In the Geometry toolbar, click Block.
- 2 In the Settings window for Block, locate the Size and Shape section.
- 3 In the Height text field, type 6.
- **4** Click to expand the **Layers** section. In the table, enter the following settings:

Layer name	Thickness (mm)
Layer 1	0.1

- **5** Find the **Layer position** subsection. Select the **Top** check box.
- 6 Click **Build All Objects**.
- 7 Click the **Zoom Extents** button in the **Graphics** toolbar.

Now define the parameters that will be used for the model. The inward current density, J_0 , corresponds to a total current of 0.7 A through a 1x1 mm square.

GLOBAL DEFINITIONS

Parameters 1

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.

3 In the table, enter the following settings:

Name	Expression	Value	Description		
T0	O[degC]	273.15 K	Temperature reference		
J0	0.7[A]/(1[mm])^2	7E5 A/m²	Inward current density		

MATERIALS

Bismuth Telluride - Bi2Te3

- I In the Materials toolbar, click Blank Material.
- 2 In the Settings window for Material, type Bismuth Telluride Bi2Te3 in the Label text field.
- **3** Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Thermal conductivity	k_iso ; kii = k_iso, kij = 0	1.6[W/(m* K)]	W/(m·K)	Basic
Density	rho	7740[kg/ m^3]	kg/m³	Basic
Heat capacity at constant pressure	Ср	154.4[J/ (kg*K)]	J/(kg·K)	Basic
Electrical conductivity	sigma_iso; sigmaii = sigma_iso, sigmaij = 0	1.1e5[S/m]	S/m	Basic
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	1	I	Basic
Seebeck coefficient	S_iso ; Sii = S_iso, Sij = 0	2e-4[V/K]	V/K	Basic

ADD MATERIAL

- I In the Materials toolbar, click 🦸 Add Material to open the Add Material window.
- 2 Go to the Add Material window.
- 3 In the tree, select Built-in>Copper.
- 4 Click Add to Component in the window toolbar.
- 5 In the Materials toolbar, click 🤼 Add Material to close the Add Material window.

MATERIALS

Copper (mat2)

- I Select Domains 1 and 3 only.
- 2 In the Settings window for Material, locate the Material Contents section.
- **3** In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Seebeck coefficient	S_iso ; Sii = S_iso, Sij = 0	6.5e- 6[V/K]	V/K	Basic

HEAT TRANSFER IN SOLIDS (HT)

Temperature I

- I In the Model Builder window, under Component I (compl) right-click Heat Transfer in Solids (ht) and choose Temperature.
- 2 Click the Wireframe Rendering button in the Graphics toolbar.
- 3 Select Boundary 3 only.
- 4 In the Settings window for Temperature, locate the Temperature section.
- **5** In the T_0 text field, type T0.

ELECTRIC CURRENTS (EC)

In the Model Builder window, under Component I (compl) click Electric Currents (ec).

Ground 1

- I In the Physics toolbar, click **Boundaries** and choose **Ground**.
- 2 Select Boundary 3 only.

Normal Current Density I


- I In the Physics toolbar, click **Boundaries** and choose Normal Current Density.
- 2 Select Boundary 10 only.
- 3 In the Settings window for Normal Current Density, locate the Normal Current Density section.
- **4** In the J_n text field, type J0.

Due to the geometrical properties, replacing the default tetrahedral mesh by a hexahedral sweep mesh is more suited.

MESH I

Swept I

- I In the Mesh toolbar, click A Swept.
- 2 In the Settings window for Swept, click to expand the Source Faces section.
- **3** Select Boundary 10 only. Now visualize the mesh and compare it with the figure below.
- 4 Click Build All.





STUDY I

In the **Home** toolbar, click **Compute**.

RESULTS

Temperature (ht)

The first default plot shows the temperature field; compare with Figure 2.

Volume 1

- I In the Model Builder window, expand the Temperature (ht) node, then click Volume I.
- 2 In the Settings window for Volume, locate the Expression section.
- 3 From the Unit list, choose degC.

4 In the Temperature (ht) toolbar, click Plot.

Electric Potential (ec)

The second default plot group shows the electric potential distribution as in Figure 4.

Add a predefined isothermal contours plot and enhance it with heat flux arrows to obtain a figure similar to Figure 3.

ADD PREDEFINED PLOT

- I In the Home toolbar, click Windows and choose Add Predefined Plot.
- 2 Go to the Add Predefined Plot window.
- 3 In the tree, select Study I/Solution I (soll)>Heat Transfer in Solids> Isothermal Contours (ht).
- 4 Click **Add Plot** in the window toolbar.

RESULTS

Isosurface I

- I In the Model Builder window, expand the Isothermal Contours (ht) node, then click Isosurface I.
- 2 In the Settings window for Isosurface, locate the Expression section.
- 3 From the Unit list, choose degC.

Arrow Volume 1

- I In the Model Builder window, right-click Isothermal Contours (ht) and choose Arrow Volume.
- 2 In the Settings window for Arrow Volume, locate the Arrow Positioning section.
- 3 Find the x grid points subsection. In the Points text field, type 2.
- 4 Find the y grid points subsection. In the Points text field, type 2.
- 5 Locate the Coloring and Style section. From the Arrow length list, choose Logarithmic.