



# Geometric Parameter Optimization of a Tuning Fork

## Introduction


---

Tuning forks have traditionally been used for tuning of musical instruments due to their ability to sound a very pure tone at their fundamental eigenfrequency. To design a tuning fork that sounds the note A, 440 Hz, you first compute the fundamental eigenfrequency and eigenmode for a design with a prong length estimated from theory. Then you use geometric parameter optimization to fine tune the prong size so that the fundamental eigenfrequency corresponds to 440 Hz.

## Model Definition

---

The model geometry is shown in [Figure 1](#). The fundamental frequency of the fork is determined by the length of the prongs, the cross-sectional geometry of the prongs, and the material properties of the fork.



*Figure 1: Tuning fork geometry.*

The following formula gives a theoretical estimation for the fundamental frequency of a tuning fork with cylindrical cross section of the prong ([Ref. 1](#)):


$$f = \frac{1.875^2 R_2}{4\pi L_p^2} \sqrt{\frac{E}{\rho}} \quad (1)$$

where  $R_2$  is the radius of the cross section of the prongs,  $E$  denotes Young's modulus, and  $\rho$  is the density. The length of the prong can be estimated as

$$L_p = L + \frac{1}{2}\pi R_1 \quad (2)$$

where  $R_1$  the radius of the base, and  $L$  is the length of the straight cylindrical part, see [Figure 1](#).

In the fundamental eigenmode, the prongs move apart and together while the handle moves up and down as shown in [Figure 2](#). Thus, the eigenmode is symmetric with a symmetry plane placed between the prongs.



*Figure 2: Vibration of the tuning fork in its fundamental eigenmode.*

The advantage with the shape of the fundamental eigenmode is that the relative displacements in the handle are very small, which makes it possible to hold the fork without damping the vibration. This also allows to make use of the theoretical estimation for the frequency [Equation 1](#) which is based on the solution for a cantilever beam representing each prong.

The parameters used in the model are:  $R_1 = 7.5$  mm and  $R_2 = 2.5$  mm. The fork material is Steel AISI 4340, for which  $E = 205$  GPa and  $\rho = 7850$  kg/m<sup>3</sup>.

For the frequency  $f = 440$  Hz, [Equation 1](#) and [Equation 2](#) give the length of the prong cylindrical part as  $L = 7.8$  cm. This presents an underestimation because the part of the prong near the base has larger bending stiffness compared to that for a straight cantilever beam.

## Results and Discussion

For the prong length of  $L = 78$  mm the simulation results in an eigenfrequency of 457 Hz. This number is higher than expected, since Equation 1 and Equation 2 underestimate the prong length due to the higher stiffness at the base compared to a straight cantilever beam.

Figure 3 shows the mode shape plot for the prong length optimized for the fundamental eigenfrequency of 440 Hz. The optimized length is 79.65 mm, which, as expected, is longer than the from theory estimated 78 mm.




Figure 3: Frequency and mode shape of the fundamental eigenmode for the optimized tuning fork.

## Notes About the COMSOL Implementation

The tuning fork geometry you are using in this model comes from Solid Edge . Using LiveLink for Solid Edge you synchronize the geometry and the parameter for the tuning fork prong length between Solid Edge and COMSOL Multiphysics. In order for this to work you need to have both programs running during modeling, and you need to make sure that the tuning fork file is the active file in Solid Edge.

## Reference

---

1. *Tuning fork*, [http://en.wikipedia.org/wiki/Tuning\\_fork](http://en.wikipedia.org/wiki/Tuning_fork)
- 

**Application Library path:** LiveLink\_for\_Solid\_Edge/Tutorials,  
\_LiveLink\_Interface/tuning\_fork\_1lse

---

## Modeling Instructions


---

- 1 In Solid Edge open the file `tuning_fork.par` located in the model's Application Library folder.
- 2 Switch to the COMSOL Desktop.




### COMSOL DESKTOP

From the **File** menu, choose **New**.

### NEW

In the **New** window, click  **Model Wizard**.

### MODEL WIZARD


- 1 In the **Model Wizard** window, click  **3D**.
- 2 In the **Select Physics** tree, select **Structural Mechanics>Solid Mechanics (solid)**.
- 3 Click **Add**.
- 4 Click  **Study**.
- 5 In the **Select Study** tree, select **General Studies>Eigenfrequency**.
- 6 Click  **Done**.

### GEOMETRY I


Make sure that the CAD Import Module kernel is used.

- 1 In the **Model Builder** window, under **Component 1 (comp1)** click **Geometry 1**.
- 2 In the **Settings** window for **Geometry**, locate the **Advanced** section.
- 3 From the **Geometry representation** list, choose **CAD kernel**.

#### *LiveLink for Solid Edge I (cad I)*

- 1 In the **Home** toolbar, click  **LiveLink** and choose **LiveLink for Solid Edge**.
- 2 In the **Settings** window for **LiveLink for Solid Edge**, locate the **Synchronize** section.
- 3 Click **Synchronize**.

After a few moments the geometry of the tuning fork appears in the **Graphics** window.



- 4 Click to expand the **Parameters in CAD Package** section. The dimensional parameter for the prong length, V873 in the Solid Edge file, has been linked to COMSOL Multiphysics and is therefore synchronized with the geometry. To manage linked parameters, you can click **Parameter Selection** on the **COMSOL Multiphysics** tab in Solid Edge. The global parameter, LL\_V873, is automatically generated in the COMSOL Multiphysics model during synchronization to enable parametric sweeps and optimization of the geometry.

## **GLOBAL DEFINITIONS**

### *Parameters I*

- 1 In the **Model Builder** window, under **Global Definitions** click **Parameters I**.
- 2 In the **Settings** window for **Parameters**, locate the **Parameters** section.

3 In the table, enter the following settings:


Name	Expression	Value	Description
LL_V873	78 [mm]	0.078 m	

## GEOMETRY I

*LiveLink for Solid Edge I (cad I)*

- 1 In the **Model Builder** window, under **Component I (comp I)>Geometry I** click **LiveLink for Solid Edge I (cad I)**.
- 2 In the **Settings** window for **LiveLink for Solid Edge**, locate the **Synchronize** section.
- 3 Click **Synchronize**.

## ADD MATERIAL

- 1 In the **Home** toolbar, click  **Add Material** to open the **Add Material** window.
- 2 Go to the **Add Material** window.
- 3 In the tree, select **Built-in>Steel AISI 4340**.
- 4 Click the right end of the **Add to Component** split button in the window toolbar.
- 5 From the menu, choose **Add to Component**.

## MESH I

*Size*

In the **Model Builder** window, under **Component I (comp I)** right-click **Mesh I** and choose **Edit Physics-Induced Sequence**.

*Free Tetrahedral I*

Change the default mesh settings to get a finer mesh that better resolves the geometry.


*Size I*

- 1 In the **Model Builder** window, right-click **Free Tetrahedral I** and choose **Size**.
- 2 In the **Settings** window for **Size**, locate the **Geometric Entity Selection** section.
- 3 From the **Geometric entity level** list, choose **Boundary**.
- 4 From the **Selection** list, choose **All boundaries**.
- 5 Locate the **Element Size** section. From the **Predefined** list, choose **Fine**.

## STUDY I

### Step 1: Eigenfrequency


Set up the study to search for the fundamental eigenfrequency.

- 1 In the **Model Builder** window, under **Study I** click **Step 1: Eigenfrequency**.
- 2 In the **Settings** window for **Eigenfrequency**, locate the **Study Settings** section.
- 3 Select the **Desired number of eigenfrequencies** check box.
- 4 In the associated text field, type 1.
- 5 In the **Search for eigenfrequencies around** text field, type 440[Hz].
- 6 In the **Home** toolbar, click  **Compute**.

## RESULTS

### Mode Shape (solid)


After the computation is finished a plot similar to the one below appears.




## STUDY I

Continue with setting up the optimization.


### Optimization

- 1 In the **Study** toolbar, click  **Optimization**.
- 2 In the **Settings** window for **Optimization**, locate the **Optimization Solver** section.
- 3 From the **Method** list, choose **BOBYQA**.
- 4 Locate the **Objective Function** section. In the table, enter the following settings:

Expression	Description	Evaluate for
abs(freq-440)	Frequency	Eigenfrequency

- 5 Locate the **Control Variables and Parameters** section. Click  **Add**.
- 6 In the table, enter the following settings:

Parameter name	Initial value	Scale	Lower bound	Upper bound
LL_V873	78 [mm]	0.01	78 [mm]	81 [mm]



- 7 In the **Study** toolbar, click  **Compute**.

## RESULTS

### Mode Shape (solid)

After the optimization is finished a plot similar to [Figure 3](#) is displayed. You can read the value of the eigenfrequency from the plot. Continue with displaying the value of the optimized prong length parameter in a table.

### Global Evaluation I


- 1 In the **Results** toolbar, click  **Global Evaluation**.
- 2 In the **Settings** window for **Global Evaluation**, click **Replace Expression** in the upper-right corner of the **Expressions** section. From the menu, choose **Solver>Control parameters>LL\_V873 - Control parameter LL\_V873 - m**.
- 3 Click  **Evaluate**.

## GEOMETRY I

### LiveLink for Solid Edge I (cad I)

- 1 In the **Model Builder** window, under **Component I (comp1)>Geometry I** click **LiveLink for Solid Edge I (cad I)**.
- 2 In the **Settings** window for **LiveLink for Solid Edge**, locate the **Parameters in CAD Package** section.
- 3 Click **Update Parameters from CAD** in the upper-right corner of the section.

*Form Union (fin)*

In the **Home** toolbar, click  **Build All**.