

# Axisymmetric Transient Heat Transfer

## *Introduction*

---

This example shows an axisymmetric transient thermal analysis with a step change to 1000°C at time 0. The example is taken from a NAFEMS benchmark collection ([Ref. 1](#)).

## *Model Definition*

---

This example considers the 0.3 m-by-0.4 m domain. For the boundary conditions, assume the following:

- The left boundary is the symmetry axis.
- The other boundaries have a temperature of 1000°C. The entire domain is at 0°C at the start, which represents a step change in temperature at the boundaries.

In the domain use the following material properties:

- The density,  $\rho$ , is 7850 kg/m<sup>3</sup>
- The heat capacity is 460 J/(kg·°C)
- The thermal conductivity is 52 W/(m·°C).


The benchmark case is described with a simulation time of 190 s.

This models doubles the simulation with two scenarios:

- 1 the temperature condition of 1000°C is maintained during all the simulation.
- 2 at  $t = 190$  s, the temperature condition is replaced by a thermal insulation condition.

## Results

The following revolved surface plot shows the temperature distribution inside the cylinder after 190 seconds:



*Figure 1: Temperature distribution after 190 seconds.*

The benchmark result for the target location ( $t = 190$  s,  $r = 0.1$  m and  $z = 0.3$  m) is a temperature of  $186.5^{\circ}\text{C}$ . The COMSOL Multiphysics model, using a default mesh with about 430 elements, gives a temperature close to  $186.5^{\circ}\text{C}$ .

The line graph below shows the temperature variation during 380 s at the target location ( $r = 0.1$  m and  $z = 0.3$  m) for the two scenarios.




Figure 2: Temperature variation at  $r = 0.1$  m and  $z = 0.3$  m for continuous heating and for thermal insulation after 190 s.

## Reference


1. A.D. Cameron, J.A. Casey, and G.B. Simpson, *NAFEMS Benchmark Tests for Thermal Analysis (Summary)*, NAFEMS, Glasgow, 1986.

**Application Library path:** COMSOL\_Multiphysics/Heat\_Transfer/  
heat\_transient\_axi




## Modeling Instructions

From the **File** menu, choose **New**.

## NEW



In the **New** window, click  **Model Wizard**.

## MODEL WIZARD

- 1 In the **Model Wizard** window, click  **2D Axisymmetric**.
- 2 In the **Select Physics** tree, select **Heat Transfer>Heat Transfer in Solids (ht)**.
- 3 Click **Add**.
- 4 Click  **Study**.
- 5 In the **Select Study** tree, select **General Studies>Time Dependent**.
- 6 Click  **Done**.

## GEOMETRY I

*Rectangle 1 (r1)*

- 1 In the **Geometry** toolbar, click  **Rectangle**.
- 2 In the **Settings** window for **Rectangle**, locate the **Size and Shape** section.
- 3 In the **Width** text field, type 0.3.
- 4 In the **Height** text field, type 0.4.
- 5 Click  **Build All Objects**.

## HEAT TRANSFER IN SOLIDS (HT)

*Temperature 1*

- 1 In the **Model Builder** window, under **Component 1 (comp1)** right-click **Heat Transfer in Solids (ht)** and choose **Temperature**.
- 2 In the **Settings** window for **Temperature**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **All boundaries**.
- 4 Locate the **Temperature** section. In the  $T_0$  text field, type 1000[degC].

*Solid 1*

- 1 In the **Model Builder** window, click **Solid 1**.
- 2 In the **Settings** window for **Solid**, locate the **Heat Conduction, Solid** section.
- 3 From the  $k$  list, choose **User defined**. In the associated text field, type 52.
- 4 Locate the **Thermodynamics, Solid** section. From the  $\rho$  list, choose **User defined**. In the associated text field, type 7850.
- 5 From the  $C_p$  list, choose **User defined**. In the associated text field, type 460.

### *Initial Values I*


- 1 In the **Model Builder** window, click **Initial Values I**.
- 2 In the **Settings** window for **Initial Values**, locate the **Initial Values** section.
- 3 In the  $T$  text field, type 0[degC].

### **STUDY I**

#### *Time Dependent - Continuous Simulation (with Heating)*

- 1 In the **Model Builder** window, under **Study I** click **Step 1: Time Dependent**.
- 2 In the **Settings** window for **Time Dependent**, type Time Dependent - Continuous Simulation (with Heating) in the **Label** text field.
- 3 Locate the **Study Settings** section. In the **Output times** text field, type range(0,10,380).

To improve time accuracy, lower the default solver tolerance:

- 4 From the **Tolerance** list, choose **User controlled**.
- 5 In the **Relative tolerance** text field, type 1e-5.
- 6 In the **Home** toolbar, click  **Compute**.


### **RESULTS**

#### *Temperature, 3D (ht)*

To get the plot shown in [Figure 1](#), just change the unit as follows:


- 1 In the **Settings** window for **3D Plot Group**, locate the **Data** section.
- 2 From the **Time (s)** list, choose **190**.

#### *Surface*

- 1 In the **Model Builder** window, expand the **Temperature, 3D (ht)** node, then click **Surface**.
- 2 In the **Settings** window for **Surface**, locate the **Expression** section.
- 3 From the **Unit** list, choose **degC**.
- 4 In the **Temperature, 3D (ht)** toolbar, click  **Plot**.


### Isothermal Contours (ht)

The second default plot group visualizes the temperature field using a contour plot.




The benchmark value for the temperature at  $t = 190$  s,  $r = 0.1$  m and  $z = 0.3$  m is  $186.5^\circ\text{C}$ . To compare the value from the simulation, evaluate the temperature at this position.

### Cut Point 2D I

- 1 In the **Results** toolbar, click  **Cut Point 2D**.
- 2 In the **Settings** window for **Cut Point 2D**, locate the **Point Data** section.
- 3 In the **R** text field, type 0.1.
- 4 In the **Z** text field, type 0.3.

### Point Evaluation I

- 1 In the **Results** toolbar, click  **Point Evaluation**.
- 2 In the **Settings** window for **Point Evaluation**, locate the **Data** section.
- 3 From the **Dataset** list, choose **Cut Point 2D I**.
- 4 From the **Time selection** list, choose **From list**.
- 5 In the **Times (s)** list, select **190**.



6 Locate the **Expressions** section. In the table, enter the following settings:

Expression	Unit	Description
T	degC	Temperature

7 Click  **Evaluate**.

As an optional extension of the model, you can add a study sequence where, starting from 190 s, the boundaries are thermally insulated.

### ADD STUDY


- 1 In the **Home** toolbar, click  **Add Study** to open the **Add Study** window.
- 2 Go to the **Add Study** window.
- 3 Find the **Studies** subsection. In the **Select Study** tree, select **General Studies> Time Dependent**.
- 4 Click **Add Study** in the window toolbar.
- 5 In the **Home** toolbar, click  **Add Study** to close the **Add Study** window.

### STUDY 2



#### *Time Dependent - First Part (with Heating)*

- 1 In the **Settings** window for **Time Dependent**, type Time Dependent - First Part (with Heating) in the **Label** text field.
- 2 Locate the **Study Settings** section. In the **Output times** text field, type range (0, 10, 190).
- 3 From the **Tolerance** list, choose **User controlled**.
- 4 In the **Relative tolerance** text field, type 1e-5.

#### *Time Dependent - Second Part (with Insulation)*



- 1 In the **Study** toolbar, click  **Study Steps** and choose **Time Dependent> Time Dependent**.
- 2 In the **Settings** window for **Time Dependent**, type Time Dependent - Second Part (with Insulation) in the **Label** text field.
- 3 Locate the **Study Settings** section. In the **Output times** text field, type range (190, 10, 380).
- 4 From the **Tolerance** list, choose **User controlled**.
- 5 In the **Relative tolerance** text field, type 1e-5.



- 6 Locate the **Physics and Variables Selection** section. Select the **Modify model configuration for study step** check box.
- 7 In the tree, select **Component 1 (Comp1)>Heat Transfer in Solids (Ht)>Temperature 1**.
- 8 Click  **Disable**.
- 9 In the **Study** toolbar, click  **Compute**.


To combine the two time-dependent simulations, add a **Combine Solutions** study step. This concatenates the two solutions and makes it possible to treat the output as a single continuous time-dependent solution.

#### *Combine Solutions*

- 1 In the **Study** toolbar, click  **Combine Solutions**.
- 2 In the **Settings** window for **Combine Solutions**, locate the **Combine Solutions Settings** section.
- 3 From the **First solution** list, choose **Study 2/Solution Store 1 (sol3)**.
- 4 In the **Study** toolbar, click  **Compute**.

## **RESULTS**


#### *Surface*

- 1 In the **Model Builder** window, expand the **Temperature, 3D (ht) 1** node, then click **Surface**.
- 2 In the **Settings** window for **Surface**, locate the **Expression** section.
- 3 From the **Unit** list, choose **degC**.
- 4 In the **Temperature, 3D (ht) 1** toolbar, click  **Plot**.


#### *Cut Point 2D - Continuous Heating*

- 1 In the **Model Builder** window, under **Results>Datasets** click **Cut Point 2D 1**.
- 2 In the **Settings** window for **Cut Point 2D**, type Cut Point 2D - Continuous Heating in the **Label** text field.


#### *Cut Point 2D - Combined Solutions*

- 1 In the **Results** toolbar, click  **Cut Point 2D**.
- 2 In the **Settings** window for **Cut Point 2D**, type Cut Point 2D - Combined Solutions in the **Label** text field.
- 3 Locate the **Data** section. From the **Dataset** list, choose **Study 2/Solution 2 (sol2)**.
- 4 Locate the **Point Data** section. In the **R** text field, type 0.1.
- 5 In the **Z** text field, type 0.3.

### *Join - Temperature Difference*

- 1 In the **Results** toolbar, click  **More Datasets** and choose **Join**.
- 2 In the **Settings** window for **Join**, type **Join - Temperature Difference** in the **Label** text field.
- 3 Locate the **Data 1** section. From the **Data** list, choose **Cut Point 2D - Continuous Heating**.
- 4 Locate the **Data 2** section. From the **Data** list, choose **Cut Point 2D - Combined Solutions**.

### *Temperature, ID*

- 1 In the **Results** toolbar, click  **ID Plot Group**.
- 2 In the **Settings** window for **ID Plot Group**, type **Temperature, ID** in the **Label** text field.
- 3 Locate the **Data** section. From the **Dataset** list, choose **None**.
- 4 Click to expand the **Title** section. From the **Title type** list, choose **Manual**.
- 5 In the **Title** text area, type **Temperature vs. Time for Continuous and Concatenated Solutions**.

### *Point Graph 1*

- 1 Right-click **Temperature, ID** and choose **Point Graph**.
- 2 In the **Settings** window for **Point Graph**, locate the **Data** section.
- 3 From the **Dataset** list, choose **Cut Point 2D - Continuous Heating**.
- 4 Click to expand the **Coloring and Style** section. Find the **Line style** subsection. From the **Line** list, choose **Dashed**.
- 5 From the **Color** list, choose **Black**.

### *Point Graph 2*

- 1 In the **Model Builder** window, right-click **Temperature, ID** and choose **Point Graph**.
- 2 In the **Settings** window for **Point Graph**, locate the **Data** section.
- 3 From the **Dataset** list, choose **Cut Point 2D - Combined Solutions**.
- 4 Locate the **Coloring and Style** section. From the **Color** list, choose **Magenta**.

### *Point Graph 1*

- 1 In the **Model Builder** window, click **Point Graph 1**.
- 2 In the **Settings** window for **Point Graph**, click to expand the **Legends** section.
- 3 Select the **Show legends** check box.
- 4 From the **Legends** list, choose **Manual**.

5 In the table, enter the following settings:

Legends
Continuous heating

*Point Graph 2*

1 In the **Model Builder** window, click **Point Graph 2**.

2 In the **Settings** window for **Point Graph**, locate the **Legends** section.

3 Select the **Show legends** check box.

4 From the **Legends** list, choose **Manual**.

5 In the table, enter the following settings:

Legends
Thermal insulation applied after 190 s


*Temperature, ID*

1 In the **Model Builder** window, click **Temperature, ID**.


2 In the **Settings** window for **ID Plot Group**, locate the **Legend** section.

3 From the **Position** list, choose **Upper left**.


4 In the **Temperature, ID** toolbar, click  **Plot**.



### Temperature Difference, 1D

- 1 In the **Home** toolbar, click  **Add Plot Group** and choose **ID Plot Group**.
- 2 In the **Settings** window for **ID Plot Group**, type Temperature Difference, 1D in the **Label** text field.
- 3 Locate the **Data** section. From the **Dataset** list, choose **Join - Temperature Difference**.
- 4 Locate the **Title** section. From the **Title type** list, choose **Manual**.
- 5 In the **Title** text area, type Temperature Difference.

### Point Graph 1

- 1 Right-click **Temperature Difference, 1D** and choose **Point Graph**.
- 2 In the **Temperature Difference, 1D** toolbar, click  **Plot**.

