



Modeling of a CPW Using Numeric TEM Ports

Introduction

This tutorial example shows how to set up port features in a physics interface when designing a coplanar waveguide (CPW) circuit that is useful for mmWave applications.




Figure 1: Coplanar waveguide (CPW) simulation model.

Model Definition

There are multiple ways to excite and terminate a CPW using ports or lumped ports. In this tutorial, a basic CPW circuit is modeled using **Numeric** type ports with the **Analyze as a TEM field** option. This configuration requires adding a **Boundary Mode Analysis** in the study and add an **Integration Line for Voltage** subfeature for each port feature to calculate the TEM mode characteristic impedance. The TEM mode characteristic impedance is calculated based on the power on port boundaries and voltage obtained from the user-defined integration through the abovementioned subfeature. The computed impedance

scales the mode field that is mapped to the port boundaries to excite or terminate the end cross-section of the circuit.

TABLE 1: KEY ITEMS TO CHARACTERIZE A GROUNDED COPLANAR WAVEGUIDE

	Physics feature	Subfeature	Study step
Item in Model Builder	Port	Integration Line for Voltage	Boundary Mode Analysis
Notable configuration	Numeric type Analyze as a TEM field Include via edges	Set on a line geometry between two conductive boundaries	

All conductive boundaries representing metalized or plated surfaces are defined as perfect electric conductors to simplify the modeling steps. If the loss due to the finite conductivity is assumed to be nonnegligible, these boundaries can be replaced by a transition boundary condition to take the loss in the model into account.

A scattering boundary conditions is applied to the outermost boundaries. A scattering boundary condition absorbs any possible radiation from the circuit and mimics an open space.

Results and Discussion

The computed S-parameters indicate that the reflection due to the impedance mismatch is marginal (below -30 dB) and the insertion loss is below 0.05 dB. When the computation is completed, three defaults plots are automatically generated. From the electric field norm plot, it is possible to see where the strong electric fields are confined, along the conductive edges around slots between the center conductor and a pair of ground planes. When performing a boundary mode analysis for each port, the default mode field plot is available with an annotation of the computed impedance value. See the *Modeling Instruction* section for more details.

Application Library path: RF_Module/Transmission_Lines_and_Waveguides/cpw_numeric_tem_port

Modeling Instructions

From the **File** menu, choose **New**.

NEW

In the **New** window, click  **Model Wizard**.

MODEL WIZARD

- 1 In the **Model Wizard** window, click  **3D**.
- 2 In the **Select Physics** tree, select **Radio Frequency>Electromagnetic Waves, Frequency Domain (emw)**.
- 3 Click **Add**.
- 4 Click  **Study**.
- 5 In the **Select Study** tree, select **Preset Studies for Selected Physics Interfaces>Boundary Mode Analysis**.
- 6 Click  **Done**.

STUDY 1

Step 1: Boundary Mode Analysis

- 1 In the **Model Builder** window, under **Study 1** click **Step 1: Boundary Mode Analysis**.
- 2 In the **Settings** window for **Boundary Mode Analysis**, locate the **Study Settings** section.
- 3 In the **Mode analysis frequency** text field, type 10[GHZ].
- 4 Select the **Search for modes around** check box. In the associated text field, type $\text{sqrt}(12.9)/1.5$.

Step 3: Boundary Mode Analysis 1

- 1 Right-click **Study 1>Step 1: Boundary Mode Analysis** and choose **Duplicate**.
- 2 Drag and drop **Step 3: Boundary Mode Analysis 1** below **Step 1: Boundary Mode Analysis**.
- 3 In the **Settings** window for **Boundary Mode Analysis**, locate the **Study Settings** section.
- 4 In the **Port name** text field, type 2.

Step 3: Frequency Domain

- 1 In the **Model Builder** window, click **Step 3: Frequency Domain**.
- 2 In the **Settings** window for **Frequency Domain**, locate the **Study Settings** section.
- 3 In the **Frequencies** text field, type 10[GHZ].

GLOBAL DEFINITIONS

Parameters 1

- 1 In the **Model Builder** window, under **Global Definitions** click **Parameters 1**.

- 2 In the **Settings** window for **Parameters**, locate the **Parameters** section.
- 3 In the table, enter the following settings:

Name	Expression	Value	Description
w_c	200[um]	2E-4 m	CPW, center conductor width
w_s	w_c+2*125[um]	4.5E-4 m	CPW, center conductor and slot width
thickness	200[um]	2E-4 m	Wafer thickness

GEOMETRY I

- 1 In the **Model Builder** window, under **Component 1 (comp1)** click **Geometry 1**.
- 2 In the **Settings** window for **Geometry**, locate the **Units** section.
- 3 From the **Length unit** list, choose **µm**.


Block 1 (blk1)

- 1 In the **Geometry** toolbar, click  **Block**.
- 2 In the **Settings** window for **Block**, locate the **Size and Shape** section.
- 3 In the **Width** text field, type 6000.
- 4 In the **Depth** text field, type 4000.
- 5 In the **Height** text field, type 2000.
- 6 Locate the **Position** section. In the **y** text field, type -500.

Block 2 (blk2)

- 1 In the **Geometry** toolbar, click  **Block**.
- 2 In the **Settings** window for **Block**, locate the **Size and Shape** section.
- 3 In the **Width** text field, type 6000.
- 4 In the **Depth** text field, type 3000.
- 5 In the **Height** text field, type thickness.
- 6 Locate the **Position** section. In the **z** text field, type 1000-thickness.
- 7 Click  **Build Selected**.

8 Click the  **Wireframe Rendering** button in the **Graphics** toolbar.



Work Plane 1 (wp1)

- 1 In the **Geometry** toolbar, click  **Work Plane**.
- 2 In the **Settings** window for **Work Plane**, locate the **Plane Definition** section.
- 3 From the **Plane type** list, choose **Face parallel**.
- 4 On the object **blk2**, select Boundary 4 only.

Work Plane 1 (wp1)>Plane Geometry

In the **Model Builder** window, click **Plane Geometry**.

Work Plane 1 (wp1)>Rectangle 1 (r1)

- 1 In the **Work Plane** toolbar, click  **Rectangle**.
- 2 In the **Settings** window for **Rectangle**, locate the **Size and Shape** section.
- 3 In the **Width** text field, type 6000.
- 4 In the **Height** text field, type w_c .
- 5 Locate the **Position** section. From the **Base** list, choose **Center**.

Work Plane 1 (wp1)>Rectangle 2 (r2)

- 1 Right-click **Component 1 (comp1)>Geometry 1>Work Plane 1 (wp1)>Plane Geometry>Rectangle 1 (r1)** and choose **Duplicate**.
- 2 In the **Settings** window for **Rectangle**, locate the **Size and Shape** section.

3 In the **Height** text field, type w_s .

Work Plane 1 (wp1)>Difference 1 (dif1)

1 In the **Work Plane** toolbar, click  **Booleans and Partitions** and choose **Difference**.


2 Select the object **r2** only.

3 In the **Settings** window for **Difference**, locate the **Difference** section.

4 Find the **Objects to subtract** subsection. Click to select the  **Activate Selection** toggle button.

5 Select the object **r1** only.

6 Right-click **Difference 1 (dif1)** and choose **Build All Objects**.



MATERIALS

Material 1 (mat1)

1 In the **Model Builder** window, under **Component 1 (comp1)** right-click **Materials** and choose **Blank Material**.

2 In the **Settings** window for **Material**, locate the **Material Contents** section.


3 In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Relative permittivity	epsilon _{nr_} iso ; epsilon _{nrii} = epsilon _{nr_} iso, epsilon _{nrij} = 0	1		Basic
Relative permeability	mu _{r_} iso ; mu _{rii} = mu _{r_} iso, mu _{rij} = 0	1		Basic
Electrical conductivity	sigma _{iso} ; sigma _{ii} = sigma _{iso} , sigma _{ij} = 0	0	S/m	Basic

Material 2 (mat2)

1 Right-click **Materials** and choose **Blank Material**.


2 Select Domain 2 only.



3 In the **Settings** window for **Material**, locate the **Material Contents** section.

Scattering Boundary Condition 1


- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Scattering Boundary Condition**.
- 2 Select Boundaries 2–4 and 14 only.



Port 1

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Port**.

2 Select Boundaries 1 and 5 only.



3 In the **Settings** window for **Port**, locate the **Port Properties** section.

4 From the **Type of port** list, choose **Numeric**.

5 Select the **Analyze as a TEM field** check box.


Integration Line for Voltage I

1 In the **Physics** toolbar, click  **Attributes** and choose **Integration Line for Voltage**.

2 In the **Settings** window for **Integration Line for Voltage**, locate the **Edge Selection** section.

3 Click  **Clear Selection**.


4 Select Edge 11 only.



Port 2

1 In the **Physics** toolbar, click  **Boundaries** and choose **Port**.

2 Select Boundaries 15 and 16 only.




3 In the **Settings** window for **Port**, locate the **Port Properties** section.

- 4 From the **Type of port** list, choose **Numeric**.
- 5 Select the **Analyze as a TEM field** check box.


Integration Line for Voltage I

- 1 In the **Physics** toolbar, click  **Attributes** and choose **Integration Line for Voltage**.
- 2 In the **Settings** window for **Integration Line for Voltage**, locate the **Edge Selection** section.
- 3 Click  **Clear Selection**.
- 4 Select Edge 31 only.
- 5 Locate the **Settings** section. Click **Toggle Voltage Drop Direction**.




MESH 1

- 1 In the **Model Builder** window, under **Component 1 (comp1)** right-click **Mesh 1** and choose **Build All**.



- 2 In the **Graphics** window toolbar, click ▼ next to  **Select Edges**, then choose **Select Boundaries**.
- 3 Click the  **Click and Hide** button in the **Graphics** toolbar.
- 4 Select Boundaries 2 and 4 only.

5 Click the  **Click and Hide** button in the **Graphics** toolbar.




6 In the **Settings** window for **Mesh**, locate the **Electromagnetic Waves, Frequency Domain (emw)** section.

7 Select the **Refine conductive edges** check box.

8 In the **Relative size to default mesh** text field, type $0.02/\text{sqrt}(12.9)$.

9 Click  **Build All**.



10 In the **Home** toolbar, click  **Compute**.

RESULTS


Multislice

- 1 In the **Model Builder** window, expand the **Electric Field (emw)** node, then click **Multislice**.
- 2 In the **Settings** window for **Multislice**, locate the **Multipane Data** section.
- 3 Find the **X-planes** subsection. In the **Planes** text field, type 0.
- 4 Find the **Y-planes** subsection. In the **Planes** text field, type 0.
- 5 Locate the **Coloring and Style** section. Click  **Change Color Table**.
- 6 In the **Color Table** dialog box, select **Thermal>HeatCameraLight** in the tree.

7 Click **OK**.

freq(1)=10 GHz

Multislice: Electric field norm (V/m)




Inspect the mode field and the computed TEM mode impedance in the following default plots.

Electric Mode Field, Port 1 (emw)

freq(1)=10 GHz

Surface: Tangential boundary mode electric field norm (V/m)



Electric Mode Field, Port 2 (emw)

freq(1)=10 GHz

Surface: Tangential boundary mode electric field norm (V/m)

