



Model created in COMSOL Multiphysics 6.4

Hepatic Tumor Ablation

Introduction

One method for removing cancerous tumors from healthy tissue is to heat the malignant tissue to a critical temperature that kills the cancer cells. This example accomplishes the localized heating by inserting a four-armed electric probe through which an electric current runs. Equations for the electric field for this case appear in the Electric Currents interface, and this example couples them to the bioheat equation, which models the temperature field in the tissue. The heat source resulting from the electric field is also known as *resistive heating* or *Joule heating*. The original model comes from S. Tungjatkusolmun and others (Ref. 1), but we have made some simplifications. For instance, while the original uses RF heating (with AC currents), the COMSOL Multiphysics model approximates the energy with DC currents.

This medical procedure removes the tumorous tissue by heating it above 45°C to 50°C. Doing so requires a local heat source, which physicians create by inserting a small electric probe. The probe is made of a trocar (the main rod) and four electrode arms as shown in Figure 1. The trocar is electrically insulated except near the electrode arms.

An electric current through the probe creates an electric field in the tissue. The field is strongest in the immediate vicinity of the probe and generates resistive heating, which dominates around the probe's electrode arms because of the strong electric field.




Figure 1: Cylindrical modeling domain with the four-armed electric probe in the middle, which is located next to a large blood vessel.

Model Definition

This tutorial uses the Bioheat Transfer interface, the Electric Currents interface and a multiphysics feature, Electromagnetic Heating, to implement a transient analysis.

The standard temperature unit in COMSOL Multiphysics is kelvin (K). This tutorial uses the Celsius temperature scale, which is more convenient for models involving the bioheat equation.

The model approximates the body tissue with a large cylinder and assumes that its boundary temperature remains at 37°C during the entire procedure. The tumor is located near the center of the cylinder and has the same thermal properties as the surrounding tissue. The model locates the probe along the cylinder's centerline such that its electrodes span the region where the tumor is located. The geometry also includes a large blood vessel.

HEAT TRANSFER

The bioheat equation governs heat transfer in the tissue

$$\delta_{ts}\rho C \frac{\partial T}{\partial t} + \nabla \cdot (-k\nabla T) = \rho_b C_b \omega_b (T_b - T) + Q_{\text{met}} + Q_{\text{ext}}$$

where δ_{ts} is a time-scaling coefficient; ρ is the tissue density (kg/m^3); C is the tissue's specific heat ($\text{J}/(\text{kg}\cdot\text{K})$); and k is its thermal conductivity ($\text{W}/(\text{m}\cdot\text{K})$). On the right side of the equality, ρ_b gives the blood's density (kg/m^3); C_b is the blood's specific heat ($\text{J}/(\text{kg}\cdot\text{K})$); ω_b is its perfusion rate ($1/\text{s}$); T_b is the arterial blood temperature (K); while Q_{met} and Q_{ext} are the heat sources from metabolism and spatial heating, respectively (W/m^3).

In this example, the bioheat equation also models heat transfer in various parts of the probe with the appropriate values for the specific heat, C ($\text{J}/(\text{kg}\cdot\text{K})$), and thermal conductivity, k ($\text{W}/(\text{m}\cdot\text{K})$). For these parts, all terms on the right-hand side are zero.

The model next sets the boundary conditions at the outer boundaries of the cylinder and at the walls of the blood vessel to a temperature of 37°C. Assume heat flux continuity on all other boundaries.

The initial temperature equals 37°C in all domains.

In addition to the heat transfer equation this model provides a calculation of the tissue damage integral. This gives an idea about the degree of tissue injury α during the process, based on the Arrhenius equation:

$$\frac{d\alpha}{dt} = A \exp\left(-\frac{\Delta E}{RT}\right)$$

where A is the frequency factor (s^{-1}) and ΔE is the activation energy for irreversible damage reaction (J/mol). These two parameters are dependent on the type of tissue. The fraction of necrotic tissue, θ_d , is then expressed by:

$$\theta_d = 1 - \exp(-\alpha)$$

ELECTRIC CURRENT

The governing equation for the Electric Currents interface is

$$-\nabla \cdot (\sigma \nabla V - \mathbf{J}^e) = Q_j$$

where V is the potential (V), σ the electric conductivity (S/m), \mathbf{J}^e an externally generated current density (A/m^2), Q_j the current source (A/m^3).

In this model both \mathbf{J}^e and Q_j are zero. The governing equation therefore simplifies into:

$$-\nabla \cdot (\sigma \nabla V) = 0.$$

The boundary conditions at the cylinder's outer boundaries is ground (0 V potential). At the electrode boundaries the potential equals 22 V. Assume continuity for all other boundaries.

The boundary conditions for the Electric Currents interface are:

$$\begin{aligned} V &= 0 && \text{on the cylinder wall} \\ V &= V_0 && \text{on the electrode surfaces} \\ \mathbf{n} \cdot (\mathbf{J}_1 - \mathbf{J}_2) &= 0 && \text{on all other boundaries} \end{aligned}$$

The boundary conditions for the bioheat equation are:

$$\begin{aligned} T &= T_b && \text{on the cylinder wall and blood-vessel wall} \\ \mathbf{n} \cdot (k_1 \nabla T_1 - k_2 \nabla T_2) &= 0 && \text{on all interior boundaries} \end{aligned}$$

The model solves the above equations with the given boundary conditions to obtain the temperature field as a function of time.

Results and Discussion

The model shows how the temperature increases with time in the tissue around the electrode.

The slice plot in [Figure 2](#) illustrates the temperature field at the end of the procedure.




Figure 2: Temperature field at time 10 minutes.

Figure 3 shows the temperature at the tip of one of the electrode arms. The temperature rises quickly until it reaches a steady-state temperature of about 97°C.




Figure 3: Temperature versus time at the tip of one of the electrode arms.

It is also interesting to visualize the region where cancer cells die, that is, where the temperature has reached at least 50°C . You can visualize this area with an isosurface for that temperature; [Figure 4](#) shows one after 10 minutes.




Figure 4: Visualization of the region that has reached 50°C after 10 minutes.

In addition to the previous figure, you can visualize the fraction of necrotic tissue in the slice plot of [Figure 5](#).




Figure 5: Fraction of necrotic tissue.

Finally, [Figure 6](#) shows the fraction of necrotic tissue at three different points above the electrode arm. Observe that necrosis happens faster next to the electrode and the trocar tip.




Figure 6: Fraction of necrotic tissue at three points above the electrode arm.

Reference


I. S. Tungjitkusolmun, S. Tyler Staelin, D. Haemmerich, J.Z. Tsai, H. Cao, J.G. Webster, F.T. Lee, Jr., D.M. Mahvi, and V.R. Vorperian, “Three-Dimensional Finite Element Analyses for Radio-Frequency Hepatic Tumor Ablation,” *IEEE Transactions on Biomedical Engineering*, vol. 49, no. 1, 2002.

Application Library path: Heat_Transfer_Module/Medical_Technology/
tumor_ablation




Modeling Instructions

From the **File** menu, choose **New**.

NEW

In the **New** window, click  **Model Wizard**.

MODEL WIZARD

- 1 In the **Model Wizard** window, click .
- 2 In the **Select Physics** tree, select **AC/DC** > **Electric Fields and Currents** > **Electric Currents (ec)**.
- 3 Click **Add**.
- 4 In the **Select Physics** tree, select **Heat Transfer** > **Bioheat Transfer (ht)**.
- 5 Click **Add**.
- 6 Click  **Study**.
- 7 In the **Select Study** tree, select **General Studies** > **Stationary**.
- 8 Click  **Done**.

GLOBAL DEFINITIONS

First, define the global parameters of the model and the geometry.

Parameters 1

- 1 In the **Model Builder** window, under **Global Definitions** click **Parameters 1**.
- 2 In the **Settings** window for **Parameters**, locate the **Parameters** section.
- 3 In the table, enter the following settings:


Name	Expression	Value	Description
rho_b	1000[kg/m^3]	1000 kg/m ³	Density, blood
c_b	4180[J/(kg*K)]	4180 J/(kg·K)	Heat capacity, blood
omega_b	6.4e-3[1/s]	0.0064 1/s	Blood perfusion rate
T_b	37[degC]	310.15 K	Arterial blood temperature
T0	37[degC]	310.15 K	Initial and boundary temperature
V0	22[V]	22 V	Electric voltage

Name	Expression	Value	Description
xc_v	26[mm]	0.026 m	Vessel cylinder center x-coordinate
a_time	10[min]	600 s	Ablation time


GEOMETRY I

- 1 In the **Model Builder** window, under **Component 1 (comp1)** click **Geometry 1**.
- 2 In the **Settings** window for **Geometry**, locate the **Units** section.
- 3 From the **Length unit** list, choose **mm**.



Cylinder 1 (cyl1)

- 1 In the **Geometry** toolbar, click  **Cylinder**.
- 2 In the **Settings** window for **Cylinder**, locate the **Size and Shape** section.
- 3 In the **Radius** text field, type 0.9144.
- 4 In the **Height** text field, type 60.
- 5 Locate the **Position** section. In the **z** text field, type 60.
- 6 Click to expand the **Layers** section. In the table, enter the following settings:





Layer name	Thickness (mm)
Layer 1	10

- 7 Clear the **Layers on side** checkbox.
- 8 Select the **Layers on bottom** checkbox.
- 9 Click  **Build Selected**.




Torus 1 (tor1)

- 1 In the **Geometry** toolbar, click  **Torus**.
- 2 In the **Settings** window for **Torus**, locate the **Size and Shape** section.
- 3 In the **Major radius** text field, type 7.5.
- 4 In the **Minor radius** text field, type 0.2667.
- 5 In the **Revolution angle** text field, type 180.
- 6 Locate the **Position** section. In the **x** text field, type 8.
- 7 In the **z** text field, type 60.
- 8 Locate the **Axis** section. From the **Axis type** list, choose **y-axis**.
- 9 Locate the **Rotation Angle** section. In the **Rotation** text field, type -90.
- 10 Click  **Build Selected**.




Rotate 1 (rot1)

- 1 In the **Geometry** toolbar, click  **Transforms** and choose **Rotate**.
- 2 Select the object **tor1** only.
- 3 In the **Settings** window for **Rotate**, locate the **Rotation** section.
- 4 Click  **Range**.
- 5 In the **Range** dialog, type 0 in the **Start** text field.
- 6 In the **Step** text field, type 90.
- 7 In the **Stop** text field, type 270.
- 8 Click **Replace**.
- 9 In the **Settings** window for **Rotate**, click  **Build Selected**.
- 10 Click the  **Zoom Extents** button in the **Graphics** toolbar.

Cylinder 2 (cyl2)


- 1 In the **Geometry** toolbar, click  **Cylinder**.
- 2 In the **Settings** window for **Cylinder**, locate the **Size and Shape** section.
- 3 In the **Radius** text field, type 5.
- 4 In the **Height** text field, type 120.
- 5 Locate the **Position** section. In the **x** text field, type x_c_v .
- 6 Click  **Build Selected**.
- 7 Click the  **Zoom Extents** button in the **Graphics** toolbar.

Cylinder 3 (cyl3)

- 1 In the **Geometry** toolbar, click  **Cylinder**.
- 2 In the **Settings** window for **Cylinder**, locate the **Size and Shape** section.
- 3 In the **Radius** text field, type 50.
- 4 In the **Height** text field, type 120.
- 5 In the **Geometry** toolbar, click  **Build All**.
- 6 Click the  **Zoom Extents** button in the **Graphics** toolbar.


DEFINITIONS

Exterior Boundaries


- 1 In the **Definitions** toolbar, click  **Explicit**.
- 2 In the **Settings** window for **Explicit**, type Exterior Boundaries in the **Label** text field.
- 3 Locate the **Input Entities** section. Select the **All domains** checkbox.

- 4 Locate the **Output Entities** section. From the **Output entities** list, choose **Adjacent boundaries**.



Liver Tissue

- 1 In the **Definitions** toolbar, click  **Explicit**.
- 2 In the **Settings** window for **Explicit**, type Liver Tissue in the **Label** text field.
- 3 Select Domain 1 only.


Blood Vessel

- 1 In the **Definitions** toolbar, click  **Explicit**.
- 2 In the **Settings** window for **Explicit**, type Blood Vessel in the **Label** text field.
- 3 Select Domain 8 only.


Electrodes

- 1 In the **Definitions** toolbar, click  **Explicit**.
- 2 In the **Settings** window for **Explicit**, type Electrodes in the **Label** text field.
- 3 Click the  **Wireframe Rendering** button in the **Graphics** toolbar.
- 4 Select Domains 2 and 5–7 only.



Trocar Tip

- 1 In the **Definitions** toolbar, click  **Explicit**.
- 2 In the **Settings** window for **Explicit**, type Trocar Tip in the **Label** text field.
- 3 Select Domain 3 only.

Trocar Base


- 1 In the **Definitions** toolbar, click  **Explicit**.
- 2 In the **Settings** window for **Explicit**, type Trocar Base in the **Label** text field.
- 3 Select Domain 4 only.

Trocar



- 1 In the **Definitions** toolbar, click  **Union**.
- 2 In the **Settings** window for **Union**, type Trocar in the **Label** text field.
- 3 Locate the **Input Entities** section. Under **Selections to add**, click  **Add**.
- 4 In the **Add** dialog, in the **Selections to add** list, choose **Trocar Tip** and **Trocar Base**.
- 5 Click **OK**.

Trocar with Electrodes



- 1 In the **Definitions** toolbar, click  **Union**.

- 2 In the **Settings** window for **Union**, type Trocar with Electrodes in the **Label** text field.
- 3 Locate the **Input Entities** section. Under **Selections to add**, click  **Add**.
- 4 In the **Add** dialog, in the **Selections to add** list, choose **Electrodes** and **Trocar**.
- 5 Click **OK**.



Tissue and Trocar with Electrodes

- 1 In the **Definitions** toolbar, click  **Union**.
- 2 In the **Settings** window for **Union**, type Tissue and Trocar with Electrodes in the **Label** text field.
- 3 Locate the **Input Entities** section. Under **Selections to add**, click  **Add**.
- 4 In the **Add** dialog, in the **Selections to add** list, choose **Liver Tissue** and **Trocar with Electrodes**.
- 5 Click **OK**.


Tissue and Trocar with Electrodes, Exterior Boundaries

- 1 In the **Definitions** toolbar, click  **Adjacent**.
- 2 In the **Settings** window for **Adjacent**, type Tissue and Trocar with Electrodes, Exterior Boundaries in the **Label** text field.
- 3 Locate the **Input Entities** section. Under **Input selections**, click  **Add**.
- 4 In the **Add** dialog, select **Tissue and Trocar with Electrodes** in the **Input selections** list.
- 5 Click **OK**.

Trocar Tip with Electrodes, Exterior Boundaries

- 1 In the **Definitions** toolbar, click  **Adjacent**.
- 2 In the **Settings** window for **Adjacent**, type Trocar Tip with Electrodes, Exterior Boundaries in the **Label** text field.
- 3 Locate the **Input Entities** section. Under **Input selections**, click  **Add**.
- 4 In the **Add** dialog, in the **Input selections** list, choose **Electrodes** and **Trocar Tip**.
- 5 Click **OK**.

ADD MATERIAL

- 1 In the **Materials** toolbar, click  **Add Material** to open the **Add Material** window.
- 2 Go to the **Add Material** window.
- 3 In the tree, select **Bioheat > Liver (human)**.
- 4 Click the **Add to Component** button in the window toolbar.

5 In the **Materials** toolbar, click  **Add Material** to close the **Add Material** window.


MATERIALS

Liver (human) (mat1)

- 1 In the **Settings** window for **Material**, locate the **Geometric Entity Selection** section.
- 2 From the **Selection** list, choose **Liver Tissue**.
- 3 Locate the **Material Contents** section. In the table, enter the following settings:


Property	Variable	Value	Unit	Property group
Electric conductivity	sigma_iso ; sigma_ii = sigma_iso, sigma_ij = 0	0.333 [S/m]	S/m	Basic
Relative permittivity	epsilon_r_iso ; epsilon_rii = epsilon_r_iso, epsilon_r_ij = 0	1		Basic

Blood

- 1 In the **Materials** toolbar, click  **Blank Material**.
- 2 In the **Settings** window for **Material**, type **Blood** in the **Label** text field.
- 3 Locate the **Geometric Entity Selection** section. From the **Selection** list, choose **Blood Vessel**.
- 4 Locate the **Material Contents** section. In the table, enter the following settings:


Property	Variable	Value	Unit	Property group
Electric conductivity	sigma_iso ; sigma_ii = sigma_iso, sigma_ij = 0	0.667 [S/m]	S/m	Basic
Relative permittivity	epsilon_r_is o ; epsilon_rii = epsilon_r_is o, epsilon_r_ij = 0	1		Basic

Electrodes

- 1 In the **Materials** toolbar, click  **Blank Material**.
- 2 In the **Settings** window for **Material**, type Electrodes in the **Label** text field.
- 3 Locate the **Geometric Entity Selection** section. From the **Selection** list, choose **Electrodes**.
- 4 Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Electric conductivity	sigma_iso ; sigma_ii = sigma_iso, sigma_ij = 0	1e8 [S/m]	S/m	Basic
Relative permittivity	epsilon_r_iso ; epsilon_rii = epsilon_r_iso, epsilon_r_ij = 0	1	l	Basic
Thermal conductivity	k_iso ; k_ii = k_iso, k_ij = 0	18 [W / (m * K)]	W / (m * K)	Basic
Density	rho	6450 [kg / m ^ 3]	kg / m ^ 3	Basic
Heat capacity at constant pressure	Cp	840 [J / (kg * K)]	J / (kg * K)	Basic


Trocar Tip

- 1 In the **Materials** toolbar, click  **Blank Material**.
- 2 In the **Settings** window for **Material**, type Trocar Tip in the **Label** text field.
- 3 Locate the **Geometric Entity Selection** section. From the **Selection** list, choose **Trocar Tip**.

4 Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Electric conductivity	sigma_iso ; sigma_ii = sigma_iso, sigma_ij = 0	4e6 [S/m]	S/m	Basic
Relative permittivity	epsilon_r_ii ; epsilon_r_ii = epsilon_r_ii, epsilon_r_ij = 0	1	1	Basic
Thermal conductivity	k_iso ; k_ii = k_iso, k_ij = 0	71 [W/ (m*K)]	W/(m·K)	Basic
Density	rho	21500 [kg/m^3]	kg/m ³	Basic
Heat capacity at constant pressure	Cp	132 [J/ (kg*K)]	J/(kg·K)	Basic

Trocar Base


- 1 In the **Materials** toolbar, click  **Blank Material**.
- 2 In the **Settings** window for **Material**, type Trocar Base in the **Label** text field.
- 3 Locate the **Geometric Entity Selection** section. From the **Selection** list, choose **Trocar Base**.

4 Locate the **Material Contents** section. In the table, enter the following settings:


Property	Variable	Value	Unit	Property group
Electric conductivity	sigma_iso ; sigma_ii = sigma_iso, sigma_ij = 0	1e-5 [S/m]	S/m	Basic
Relative permittivity	epsilon_r_iso ; epsilon_rii = epsilon_r_iso, epsilon_r_ij = 0	1	I	Basic
Thermal conductivity	k_iso ; k_ii = k_iso, k_ij = 0	0.026 [W/ (m*K)]	W/(m·K)	Basic
Density	rho	70 [kg /m^3]	kg/m ³	Basic
Heat capacity at constant pressure	Cp	1045 [J / (kg*K)]	J/(kg·K)	Basic

ELECTRIC CURRENTS (EC)

Ground I

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Ground**.
- 2 In the **Settings** window for **Ground**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **Exterior Boundaries**.

Electric Potential I

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Electric Potential**.
- 2 In the **Settings** window for **Electric Potential**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **Trocar Tip with Electrodes, Exterior Boundaries**.
- 4 Locate the **Electric Potential** section. In the V_0 text field, type V_0 .

BIOHEAT TRANSFER (HT)

- 1 In the **Model Builder** window, under **Component 1 (comp1)** click **Bioheat Transfer (ht)**.
- 2 In the **Settings** window for **Bioheat Transfer**, locate the **Domain Selection** section.
- 3 From the **Selection** list, choose **Tissue and Trocar with Electrodes**.


Biological Tissue I

In the **Model Builder** window, under **Component 1 (comp1) > Bioheat Transfer (ht)** click **Biological Tissue I**.

Thermal Damage I

1 In the **Physics** toolbar, click  **Attributes** and choose **Thermal Damage**.

To reduce computation time, enable the **Use local time integration** option, available under **Advanced Physics Options**.

2 Click the  **Show More Options** button in the **Model Builder** toolbar.

3 In the **Show More Options** dialog, in the tree, select the checkbox for the node **Physics > Advanced Physics Options**.

4 Click **OK**.

5 In the **Settings** window for **Thermal Damage**, locate the **Damaged Tissue** section.

6 From the **Transformation model** list, choose **Arrhenius kinetics**.

7 Click to expand the **Discretization** section. Select the **Use local time integration** checkbox.

Bioheat I

1 In the **Model Builder** window, click **Bioheat I**.

2 In the **Settings** window for **Bioheat**, locate the **Bioheat** section.

3 In the T_b text field, type T_b .

4 In the $C_{p,b}$ text field, type c_b .

5 In the ω_b text field, type ω_b .

6 In the ρ_b text field, type ρ_b .

Initial Values I

1 In the **Model Builder** window, under **Component 1 (comp1) > Bioheat Transfer (ht)** click **Initial Values I**.

2 In the **Settings** window for **Initial Values**, locate the **Initial Values** section.

3 In the T text field, type T_0 .


Solid I

1 In the **Physics** toolbar, click  **Domains** and choose **Solid**.

2 In the **Settings** window for **Solid**, locate the **Domain Selection** section.


3 From the **Selection** list, choose **Trocar with Electrodes**.

Temperature 1

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Temperature**.
- 2 In the **Settings** window for **Temperature**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **Tissue and Trocar with Electrodes, Exterior Boundaries**.
- 4 Locate the **Temperature** section. In the T_0 text field, type T_b.

MULTIPHYSICS

Electromagnetic Heating 1 (emh1)

- In the **Physics** toolbar, click  **Multiphysics Couplings** and choose **Domain > Electromagnetic Heating**.

MESH 1

- In the **Model Builder** window, under **Component 1 (comp1)** right-click **Mesh 1** and choose **Build All**.


STUDY 1

Given the time scale of the tumor ablation process, the electric field can be assumed to be stationary. Additionally, the electrical properties of the materials in the model are considered constant. As a result, the electric field can be computed independently of the thermal analysis. The study is therefore divided into two distinct steps. In the first, stationary step, the electric field is calculated. In the second, time-dependent step, the temperature distribution and tissue damage indicator are computed.

Step 1: Stationary

- 1 In the **Model Builder** window, under **Study 1** click **Step 1: Stationary**.
- 2 In the **Settings** window for **Stationary**, locate the **Physics and Variables Selection** section.
- 3 In the **Solve for** column of the table, under **Component 1 (comp1)**, clear the checkbox for **Bioheat Transfer (ht)**.
- 4 In the **Solve for** column of the table, under **Component 1 (comp1) > Multiphysics**, clear the checkbox for **Electromagnetic Heating 1 (emh1)**.

Step 2: Time Dependent


- 1 In the **Study** toolbar, click  **Time Dependent**.
- 2 In the **Settings** window for **Time Dependent**, locate the **Study Settings** section.
- 3 From the **Time unit** list, choose **min**.
- 4 In the **Output times** text field, type range(0,a_time/4,a_time).

- 5 Locate the **Physics and Variables Selection** section. In the **Solve for** column of the table, under **Component I (comp1)**, clear the checkbox for **Electric Currents (ec)**.


DEFINITIONS

Add probes to save the fraction of necrotic tissue and the temperature over time at some specified points.

Domain Point Probe 1

- 1 In the **Definitions** toolbar, click  **Probes** and choose **Domain Point Probe**.
- 2 In the **Settings** window for **Domain Point Probe**, locate the **Point Selection** section.
- 3 In row **Coordinates**, set **x** to -4.
- 4 In row **Coordinates**, set **z** to 65.

Point Probe Expression 1 (ppb1)

- 1 In the **Model Builder** window, expand the **Domain Point Probe 1** node, then click **Point Probe Expression 1 (ppb1)**.
- 2 In the **Settings** window for **Point Probe Expression**, click **Replace Expression** in the upper-right corner of the **Expression** section. From the menu, choose **Component I (comp1) > Bioheat Transfer > Irreversible transformation > ht.theta_d - Fraction of damage - 1**.
- 3 Click to expand the **Table and Window Settings** section. Click  **Add Plot Window**.


Domain Point Probe 2

- 1 In the **Model Builder** window, under **Component I (comp1) > Definitions** right-click **Domain Point Probe 1** and choose **Duplicate**.
- 2 In the **Settings** window for **Domain Point Probe**, locate the **Point Selection** section.
- 3 In row **Coordinates**, set **x** to -12.

Domain Point Probe 3

- 1 Right-click **Domain Point Probe 1** and choose **Duplicate**.
- 2 In the **Settings** window for **Domain Point Probe**, locate the **Point Selection** section.
- 3 In row **Coordinates**, set **x** to -20.

Domain Point Probe 4

- 1 In the **Definitions** toolbar, click  **Probes** and choose **Domain Point Probe**.
- 2 In the **Settings** window for **Domain Point Probe**, locate the **Point Selection** section.
- 3 In row **Coordinates**, set **x** to -0.2667.
- 4 In row **Coordinates**, set **y** to 15.5.
- 5 In row **Coordinates**, set **z** to 60.

Point Probe Expression 4 (ppb4)

- 1 In the **Model Builder** window, expand the **Domain Point Probe 4** node, then click **Point Probe Expression 4 (ppb4)**.
- 2 In the **Settings** window for **Point Probe Expression**, click **Replace Expression** in the upper-right corner of the **Expression** section. From the menu, choose **Component 1 (comp1) > Bioheat Transfer > Temperature > T - Temperature - K**.
- 3 Locate the **Table and Window Settings** section. Click **+ Add Plot Window**.
- 4 Locate the **Expression** section. From the **Table and plot unit** list, choose **°C**.

STUDY 1

In the **Study** toolbar, click **= Compute**.

RESULTS

The first default plot shows the change of damage fraction in probe locations over time.

Damaged Tissue, 1D

- 1 In the **Model Builder** window, under **Results** click **Probe Plot Group 1**.
- 2 In the **Settings** window for **ID Plot Group**, type **Damaged Tissue, 1D** in the **Label** text field.
- 3 Click to expand the **Title** section. From the **Title type** list, choose **Manual**.
- 4 In the **Title** text area, type **Fraction of damage at the probe locations over time**.
- 5 Locate the **Plot Settings** section.
- 6 Select the **y-axis label** checkbox. In the associated text field, type **Fraction of damage (1)**.
- 7 Locate the **Legend** section. From the **Position** list, choose **Lower right**.

Probe Table Graph 1


- 1 In the **Model Builder** window, expand the **Damaged Tissue, 1D** node, then click **Probe Table Graph 1**.
- 2 In the **Settings** window for **Table Graph**, click to expand the **Legends** section.
- 3 From the **Legends** list, choose **Manual**.
- 4 In the table, enter the following settings:

Legends
Point: (-4, 0, 65)

Legends

Point: (-12, 0, 65)

Point: (-20, 0, 65)

- 5 In the **Damaged Tissue, ID** toolbar, click  **Plot**.

Generate plot to show the temperature at one of the electrode tips over time.

Temperature at One Electrode Tip

- 1 In the **Model Builder** window, under **Results** click **Probe Plot Group 2**.
- 2 In the **Settings** window for **ID Plot Group**, type Temperature at One Electrode Tip in the **Label** text field.
- 3 Locate the **Plot Settings** section.
- 4 Select the **y-axis label** checkbox. In the associated text field, type Temperature (°C).
- 5 Locate the **Title** section. From the **Title type** list, choose **Manual**.
- 6 In the **Title** text area, type Temperature at one of the electrode tip over time.
- 7 Locate the **Legend** section. From the **Position** list, choose **Lower right**.

Probe Table Graph 1

- 1 In the **Model Builder** window, expand the **Temperature at One Electrode Tip** node, then click **Probe Table Graph 1**.
- 2 In the **Settings** window for **Table Graph**, locate the **Legends** section.
- 3 From the **Legends** list, choose **Manual**.
- 4 In the table, enter the following settings:

Legends

Point: (-0.2667, 15.5, 60)

- 5 In the **Temperature at One Electrode Tip** toolbar, click  **Plot**.


Electric Potential (ec)


The third default plot shows the electric potential in the volume. Modify it to display the results on the appropriate slices.

Volume 1

- 1 In the **Model Builder** window, expand the **Electric Potential (ec)** node.
- 2 Right-click **Volume 1** and choose **Delete**.

Multislice 1

- 1 In the **Electric Potential (ec)** toolbar, click  **More Plots** and choose **Multislice**.

- 2 In the **Settings** window for **Multislice**, locate the **Multipane Data** section.
- 3 Find the **z-planes** subsection. In the **Planes** text field, type 0.
- 4 Locate the **Coloring and Style** section. From the **Color table** list, choose **Dipole**.
- 5 In the **Electric Potential (ec)** toolbar, click  **Plot**.


Electric Field (ec)

The fourth default plot shows the electric field norm on slices. You can remove one of the slices for better visualization.

Multislice I

- 1 In the **Model Builder** window, expand the **Electric Field (ec)** node, then click **Multislice I**.
- 2 In the **Settings** window for **Multislice**, locate the **Multipane Data** section.
- 3 Find the **z-planes** subsection. From the **Entry method** list, choose **Number of planes**.
- 4 In the **Planes** text field, type 0.

Streamline Multislice I

- 1 In the **Model Builder** window, click **Streamline Multislice I**.
- 2 In the **Settings** window for **Streamline Multislice**, locate the **Multipane Data** section.
- 3 Find the **z-planes** subsection. From the **Entry method** list, choose **Number of planes**.
- 4 In the **Planes** text field, type 0.
- 5 In the **Electric Field (ec)** toolbar, click  **Plot**.

Temperature (ht)


The last default plot shows the volume distribution of temperature at the final time.

To reproduce the two-slice plot of the temperature at 10 minutes shown in [Figure 2](#), use one of the plots from the **Result Templates**.

Before adding the multislice plot, delete the default **Temperature** node.

- 1 In the **Model Builder** window, under **Results** right-click **Temperature (ht)** and choose **Delete**. Click **Yes** to confirm.



RESULT TEMPLATES

- 1 In the **Results** toolbar, click  **Result Templates** to open the **Result Templates** window.
- 2 Go to the **Result Templates** window.
- 3 In the tree, select **Study 1/Solution 1 (sol1) > Bioheat Transfer > Temperature, Multislice (ht)**.
- 4 Click the **Add Result Template** button in the window toolbar.



- 5 In the **Results** toolbar, click  **Result Templates** to close the **Result Templates** window.

RESULTS

Multislice 1

- 1 In the **Model Builder** window, expand the **Temperature, Multislice (ht)** node, then click **Multislice 1**.
- 2 In the **Settings** window for **Multislice**, locate the **Multipane Data** section.
- 3 Find the **z-planes** subsection. In the **Planes** text field, type 0.
- 4 Locate the **Expression** section. From the **Unit** list, choose °C.
- 5 In the **Temperature, Multislice (ht)** toolbar, click  **Plot**.
- 6 Click the  **Zoom In** button in the **Graphics** toolbar.

RESULT TEMPLATES


- 1 In the **Results** toolbar, click  **Result Templates** to open the **Result Templates** window.
Use another plot from the **Result Templates** to see isothermal contours for the final time.
To reproduce [Figure 4](#), follow the next steps:
- 2 Go to the **Result Templates** window.
- 3 In the tree, select **Study 1/Solution 1 (sol1) > Bioheat Transfer > Isothermal Contours (ht)**.
- 4 Click the **Add Result Template** button in the window toolbar.
- 5 In the **Results** toolbar, click  **Result Templates** to close the **Result Templates** window.

RESULTS



Isosurface 1

- 1 In the **Model Builder** window, expand the **Isothermal Contours (ht)** node, then click **Isosurface 1**.
- 2 In the **Settings** window for **Isosurface**, locate the **Expression** section.
- 3 From the **Unit** list, choose °C.
- 4 Locate the **Levels** section. From the **Entry method** list, choose **Levels**.
- 5 In the **Levels** text field, type 50.

Isothermal Contours (ht)


- 1 In the **Model Builder** window, click **Isothermal Contours (ht)**.
- 2 In the **Isothermal Contours (ht)** toolbar, click  **Plot**.

RESULT TEMPLATES

- 1 In the **Results** toolbar, click  **Result Templates** to open the **Result Templates** window.
Add another plot from the **Result Templates** to see two-slice distribution of damaged tissue.
- 2 Go to the **Result Templates** window.
- 3 In the tree, select **Study 1/Solution 1 (sol1) > Bioheat Transfer > Damaged Tissue, Multislice (ht)**.
- 4 Click the **Add Result Template** button in the window toolbar.
- 5 In the **Results** toolbar, click  **Result Templates** to close the **Result Templates** window.

RESULTS

Multislice 1

- 1 In the **Model Builder** window, expand the **Damaged Tissue, Multislice (ht)** node, then click **Multislice 1**.
- 2 In the **Settings** window for **Multislice**, locate the **Multipane Data** section.
- 3 Find the **z-planes** subsection. In the **Planes** text field, type 0.
- 4 In the **Damaged Tissue, Multislice (ht)** toolbar, click  **Plot**.