



Model created in COMSOL Multiphysics 6.4

# Shape Optimization of an MBB Beam

## *Introduction*

---

Shape optimization can be used to alter the geometry of an existing product to improve its performance, but it can also be used as a postprocessing step for topology optimization. This model takes the design found in the model [Topology Optimization of an MBB Beam](#) and uses the **Free Shape Boundary** feature to further improve the stiffness without increasing the mass. The magnitude of the deformations in shape optimization can sometimes be limited by inverted elements. However, this is less of an issue with topology-optimized designs, because the design is already near optimality.

## *Model Definition*

---

The result of topology optimization can be converted to a geometry by taking the 0.5 contour of the *filtered material volume factor* or the *projected material volume factor*. In theory the two are identical, but in practice the fields are approximated with a linear representation on a refined mesh, and therefore it can be preferable to use the contour of the *filtered material volume factor*. This means that it is the contour of the field on the left in [Figure 1](#) that will be the starting point of the model.




*Figure 1: The result of Topology Optimization of an MBB Beam is shown with the filtered material volume factor to the left and the projected material volume factor to the right.*

The model uses the **Free Shape Symmetry** feature to prevent the design from going outside the box of the original topology optimization problem.

## Results and Discussion

---

The Helmholtz filter used by the **Density Model** in [Topology Optimization of an MBB Beam](#) is known to cause 90-degree angles on the boundaries of the design domain. The shape optimization changes this, because it is a detail that is not optimal, but it also repositions the triangular holes as seen in [Figure 2](#).



*Figure 2: The default shape optimization plot shows the edges of the old and new geometry in gray and black, respectively. An arrow plot of the actual displacement is colored with the relative normal boundary displacement. The colors of the arrows thus indicate that the shape deformation is not limited by the maximum displacement.*

## Notes About the COMSOL Implementation

---

This model combines the **Shape Optimization** and **Solid Mechanics** interfaces. The topology-optimized design can be extracted in several ways, but it is best to combine a **Filter** dataset, a **Mesh Part**, and an **Import** geometry feature because this allows recycling of the selections.

---


**Application Library path:** Optimization\_Module/Shape\_Optimization/  
mbb\_beam\_shape\_optimization

---

## *Modeling Instructions*



---

### APPLICATION LIBRARIES

- 1 From the **File** menu, choose **Application Libraries**.
- 2 In the **Application Libraries** window, select **Optimization Module > Topology Optimization > mbb\_beam\_optimization** in the tree.
- 3 Click  **Open**.

### RESULTS

#### *Filter 1*

- 1 In the **Results** toolbar, click  **More Datasets** and choose **Filter**.
- 2 In the **Settings** window for **Filter**, locate the **Data** section.
- 3 From the **Dataset** list, choose **Optimization/Parametric Solutions 1 (sol2)**.
- 4 Locate the **Expression** section. In the **Expression** text field, type `dtopo1.theta_f`.
- 5 Locate the **Filter** section. In the **Lower bound** text field, type `0.5`.
- 6 In the **Results** toolbar, click  **Attributes** and choose **Create Mesh Part**.

### MESH PART 1

- 1 In the **Model Builder** window, under **Global Definitions > Mesh Parts** right-click **Mesh Part 1** and choose **Build All**.
- 2 Right-click **Global Definitions > Mesh Parts > Mesh Part 1** and choose **Create Geometry**.


### COMPONENT 1: TOPOLOGY OPTIMIZATION

In the **Settings** window for **Component**, type **Component 1: Topology Optimization** in the **Label** text field.


### COMPONENT 2: SHAPE OPTIMIZATION

- 1 In the **Model Builder** window, click **Component 2 (comp2)**.
- 2 In the **Settings** window for **Component**, type **Component 2: Shape Optimization** in the **Label** text field.



## GEOMETRY 2

In the **Home** toolbar, click  **Build All**.



### *Moving Boundaries*

- 1 In the **Geometry** toolbar, click  **Selections** and choose **Box Selection**.
- 2 In the **Settings** window for **Box Selection**, type *Moving Boundaries* in the **Label** text field.
- 3 Locate the **Geometric Entity Level** section. From the **Level** list, choose **Boundary**.
- 4 Locate the **Box Limits** section. In the **x minimum** text field, type  $a*0.001$ .
- 5 In the **x maximum** text field, type  $a*0.999$ .
- 6 In the **y minimum** text field, type  $b*0.001$ .
- 7 In the **y maximum** text field, type  $b*0.999$ .



### *Roller Boundaries*

- 1 In the **Geometry** toolbar, click  **Selections** and choose **Complement Selection**.
- 2 In the **Settings** window for **Complement Selection**, locate the **Geometric Entity Level** section.
- 3 From the **Level** list, choose **Boundary**.
- 4 Locate the **Input Entities** section. Click  **Add**.
- 5 In the **Add** dialog, in the **Selections to invert** list, choose **Load Boundary (Import I)**, **Symmetry y (Import I)**, **Symmetry x (Import I)**, and **Moving Boundaries**.
- 6 Click **OK**.
- 7 In the **Settings** window for **Complement Selection**, type *Roller Boundaries* in the **Label** text field.

## ADD PHYSICS


- 1 In the **Home** toolbar, click  **Add Physics** to open the **Add Physics** window.
- 2 Go to the **Add Physics** window.
- 3 In the tree, select **Structural Mechanics > Solid Mechanics (solid)**.
- 4 Find the **Physics interfaces in study** subsection. In the table, clear the **Solve** checkbox for **Optimization**.
- 5 Click the **Add to Component 2: Shape Optimization** button in the window toolbar.
- 6 In the **Home** toolbar, click  **Add Physics** to close the **Add Physics** window.

## ADD MATERIAL


- 1 In the **Materials** toolbar, click  **Add Material** to open the **Add Material** window.
- 2 Go to the **Add Material** window.
- 3 In the tree, select **Built-in > Structural steel**.
- 4 Click the **Add to Component** button in the window toolbar.
- 5 In the **Materials** toolbar, click  **Add Material** to close the **Add Material** window.

## SOLID MECHANICS 2 (SOLID2)


### *Roller 1*

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Roller**.
- 2 In the **Settings** window for **Roller**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **Symmetry x (Import 1)**.

### *Prescribed Displacement 1*

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Prescribed Displacement**.
- 2 In the **Settings** window for **Prescribed Displacement**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **Symmetry y (Import 1)**.
- 4 Locate the **Prescribed Displacement** section. From the **Displacement in y direction** list, choose **Prescribed**.

### *Boundary Load 1*

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Boundary Load**.
- 2 In the **Settings** window for **Boundary Load**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **Load Boundary (Import 1)**.
- 4 Locate the **Force** section. From the **Load type** list, choose **Total force**.
- 5 Specify the  $\mathbf{F}_{\text{tot}}$  vector as

0	x
-100 [kN]	y

## MESH 2

- 1 In the **Model Builder** window, under **Component 2: Shape Optimization (comp2)** click **Mesh 2**.
- 2 In the **Settings** window for **Mesh**, locate the **Physics-Controlled Mesh** section.

3 From the **Element size** list, choose **Extra fine**.

4 Click  **Build All**.

### *Free Triangular 2*

In the **Mesh** toolbar, click  **Free Triangular**.

### *Size*

1 In the **Model Builder** window, click **Size**.

2 In the **Settings** window for **Size**, click to expand the **Element Size Parameters** section.

3 In the **Maximum element growth rate** text field, type **Inf**.

4 In the **Curvature factor** text field, type **Inf**.

5 In the **Resolution of narrow regions** text field, type **0**.

6 Click  **Build All**.

### **ADD STUDY**

1 In the **Home** toolbar, click  **Add Study** to open the **Add Study** window.

2 Go to the **Add Study** window.

3 Find the **Studies** subsection. In the **Select Study** tree, select **General Studies > Stationary**.

4 Find the **Physics interfaces in study** subsection. In the table, clear the **Solve** checkbox for **Solid Mechanics (solid)**.

5 Click the **Add Study** button in the window toolbar.

6 In the **Home** toolbar, click  **Add Study** to close the **Add Study** window.

### **STUDY 1: TOPOLOGY OPTIMIZATION**

In the **Settings** window for **Study**, type **Study 1: Topology Optimization** in the **Label** text field.

### **STUDY 2: VERIFICATION**

1 In the **Model Builder** window, click **Study 2**.

2 In the **Settings** window for **Study**, type **Study 2: Verification** in the **Label** text field.

3 In the **Study** toolbar, click  **Compute**.

### **RESULTS**

#### *Topology Optimization*


In the **Model Builder** window, under **Results** right-click **Topology Optimization** and choose **Delete**.

## COMPONENT 2: SHAPE OPTIMIZATION (COMP2)


### *Free Shape Domain I*

In the **Physics** toolbar, click  **Optimization** and choose **Shape Optimization**.

### *Symmetry/Roller I*

- 1 In the **Shape Optimization** toolbar, click  **Symmetry/Roller**.
- 2 In the **Settings** window for **Symmetry/Roller**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **Roller Boundaries**.

### *Free Shape Boundary I*

- 1 In the **Shape Optimization** toolbar, click  **Free Shape Boundary**.
- 2 In the **Settings** window for **Free Shape Boundary**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **Moving Boundaries**.
- 4 Locate the **Control Variable Settings** section. In the text field, type 0.1.
- 5 Locate the **Filtering** section. From the  $R_{\min}$  list, choose **Medium**.

## STUDY 1: TOPOLOGY OPTIMIZATION


### *Step 1: Stationary*


- 1 In the **Model Builder** window, expand the **Study 1: Topology Optimization** node, then click **Step 1: Stationary**.
- 2 In the **Settings** window for **Stationary**, locate the **Physics and Variables Selection** section.
- 3 In the **Solve for** column of the table, under **Component 2: Shape Optimization (comp2)**, clear the checkbox for **Deformed Geometry**.

## STUDY 2: VERIFICATION

- 1 In the **Model Builder** window, under **Study 2: Verification** click **Step 1: Stationary**.
- 2 In the **Settings** window for **Stationary**, locate the **Physics and Variables Selection** section.
- 3 In the **Solve for** column of the table, under **Component 2: Shape Optimization (comp2)**, clear the checkbox for **Deformed Geometry**.
- 4 In the **Solve for** column of the table, under **Component 1: Topology Optimization (comp1)**, clear the checkbox for **Topology Optimization**.


## ADD STUDY

- 1 In the **Home** toolbar, click  **Add Study** to open the **Add Study** window.
- 2 Go to the **Add Study** window.

- 3 Find the **Studies** subsection. In the **Select Study** tree, select **General Studies > Stationary**.
- 4 Find the **Physics interfaces in study** subsection. In the table, clear the **Solve** checkbox for **Solid Mechanics (solid)**.
- 5 Click the **Add Study** button in the window toolbar.
- 6 In the **Home** toolbar, click  **Add Study** to close the **Add Study** window.


### STUDY 3

#### Shape Optimization

- 1 In the **Study** toolbar, click  **Optimization** and choose **Shape Optimization**.
- 2 In the **Settings** window for **Shape Optimization**, locate the **Optimization Solver** section.
- 3 Clear the **Move limits** checkbox.
- 4 In the **Maximum number of iterations** text field, type 25.
- 5 Click **Add Expression** in the upper-right corner of the **Objective Function** section. From the menu, choose **Component 2: Shape Optimization (comp2) > Solid Mechanics 2 > Global > comp2.solid2.Ws\_tot - Total elastic strain energy - J**.
- 6 Locate the **Objective Function** section. Find the **Objective settings** subsection. From the **Objective scaling** list, choose **Initial solution based**.
- 7 Locate the **Control Variables** section. In the table, clear the **Solve for** checkbox for **Density Model 1 (dtopo1)**.
- 8 Click **Add Expression** in the upper-right corner of the **Constraints** section. From the menu, choose **Component 2: Shape Optimization (comp2) > Definitions > Free Shape Domain 1 > comp2.fsd1.area - Free shape area - m<sup>2</sup>**.
- 9 Locate the **Constraints** section. In the table, enter the following settings:

Expression	Lower bound	Upper bound
comp2.fsd1.area/a/b		volfrac

#### Step 1: Stationary

- 1 In the **Model Builder** window, click **Step 1: Stationary**.
- 2 In the **Settings** window for **Stationary**, locate the **Physics and Variables Selection** section.
- 3 In the **Solve for** column of the table, under **Component 1: Topology Optimization (comp1)**, clear the checkbox for **Topology Optimization**.
- 4 In the **Study** toolbar, click  **Get Initial Value**.


## RESULTS

### *Topology Optimization*



In the **Model Builder** window, under **Results** right-click **Topology Optimization** and choose **Delete**.

## STUDY 3


### *Shape Optimization*

- 1 In the **Model Builder** window, under **Study 3** click **Shape Optimization**.
- 2 In the **Settings** window for **Shape Optimization**, click to expand the **Output** section.
- 3 Select the **Plot** checkbox.
- 4 From the **Plot group** list, choose **Shape Optimization**.
- 5 In the **Model Builder** window, click **Study 3**.
- 6 In the **Settings** window for **Study**, type Study 3: Shape Optimization in the **Label** text field.
- 7 In the **Study** toolbar, click  **Compute**.

## RESULTS

- 1 Click the  **Zoom Extents** button in the **Graphics** toolbar.
- 2 In the **Model Builder** window, under **Results** click **Shape Optimization**.
- 3 In the **Shape Optimization** toolbar, click  **Plot**.

### *Shape Optimization (alternative plot)*

- 1 In the **Results** toolbar, click  **2D Plot Group**.
- 2 In the **Settings** window for **2D Plot Group**, type Shape Optimization (alternative plot) in the **Label** text field.
- 3 Locate the **Data** section. From the **Dataset** list, choose **Study 3: Shape Optimization/Solution 6 (6) (sol6)**.
- 4 Locate the **Plot Settings** section. Clear the **Plot dataset edges** checkbox.

### *Surface 1*

- 1 Right-click **Shape Optimization (alternative plot)** and choose **Surface**.
- 2 In the **Settings** window for **Surface**, locate the **Data** section.
- 3 From the **Dataset** list, choose **Study 2: Verification/Solution 5 (4) (sol5)**.
- 4 Locate the **Expression** section. In the **Expression** text field, type 1.
- 5 Locate the **Coloring and Style** section. From the **Coloring** list, choose **Uniform**.

6 From the **Color** list, choose **Gray**.



#### *Surface 2*

- 1 In the **Model Builder** window, right-click **Shape Optimization (alternative plot)** and choose **Surface**.
- 2 In the **Settings** window for **Surface**, locate the **Expression** section.
- 3 In the **Expression** text field, type 1.
- 4 Locate the **Coloring and Style** section. From the **Coloring** list, choose **Uniform**.

#### *Line 1*

- 1 Right-click **Shape Optimization (alternative plot)** and choose **Line**.
- 2 In the **Settings** window for **Line**, locate the **Data** section.
- 3 From the **Dataset** list, choose **Study 2: Verification/Solution 5 (4) (sol5)**.
- 4 Locate the **Coloring and Style** section. From the **Line type** list, choose **Tube**.
- 5 Select the **Radius scale factor** checkbox. In the associated text field, type 0.0035.
- 6 From the **Coloring** list, choose **Uniform**.
- 7 From the **Color** list, choose **Gray**.

#### *Line 2*

- 1 Right-click **Shape Optimization (alternative plot)** and choose **Line**.
- 2 In the **Settings** window for **Line**, locate the **Expression** section.
- 3 In the **Expression** text field, type 1.
- 4 Locate the **Coloring and Style** section. From the **Coloring** list, choose **Uniform**.
- 5 From the **Color** list, choose **Black**.
- 6 From the **Line type** list, choose **Tube**.
- 7 Select the **Radius scale factor** checkbox. In the associated text field, type 0.0035.
- 8 In the **Shape Optimization (alternative plot)** toolbar, click  **Plot**.
- 9 Click the  **Zoom Extents** button in the **Graphics** toolbar.

#### *Shaped Optimized Stress (solid2)*

- 1 In the **Model Builder** window, under **Results** click **Stress (solid2) 1**.
- 2 In the **Settings** window for **2D Plot Group**, type Shaped Optimized Stress (solid2) in the **Label** text field.